

Restraints

GENERAL

AIR BAG MODULE

SUPPLEMENTAL RESTRAINT SYSTEM CONTROL MODULE(SRSCM)

SRS CONTROL MODULE

SEAT BELT PRETENSIONER

SEAT BELT PRETENSIONER

AIR BAG MODULE (DRIVER SIDE)

AIR BAG MODULE AND CLOCK SPRING

SRS CONTROL SYSTEM

FRONT IMPACT SENSOR (FIS)

SIDE IMPACT SENSOR (SIS)

AIR BAG MODULE (PASSENGER SIDE)

AIR BAG MODULE

TROUBLESHOOTING

AIR BAG MODULE (CURTAIN AIR BAG)

AIR BAG MODULE DISPOSAL

GENERAL

GENERAL EFAC12FD

The supplemental restraint system (SRS) is designed to supplement the seat belt to help reduce the risk or severity of injury to the driver and passenger by activating and deploying the driver, passenger, side airbag and belt pretensioner in certain frontal or side collisions.

The SRS (Airbag) consists of : a driver side airbag module located in the center of the steering wheel, which contains the folded cushion and an inflator unit ; a passenger side airbag module located in the passenger side crash pad contains the folded cushion assembled with inflator unit ; side airbag modules located in the front seat contain the folded cushion and an inflator unit ; curtain airbag modules located inside of the headliner which contains folded cushions and inflator units. The impact sensing function of the SRSCM is carried out by electronic accelerometer that continuously measure the vehicle's acceleration and delivers a corresponding signal through amplifying and filtering circuitry to the microprocessor.

SRSCM (SRS CONTROL MODULE)

SRSCM will detect front impact with front impact sensor, and side impact with side impact sensor, and determine airbag module deployment.

1. DC/DC converter: DC/DC converter in power supply unit includes up/down transformer converter, and provide ignition voltage for 2 front airbag ignition circuits and the internal operation voltage of the SRSCM. If the internal operation voltage is below critical value setting, it will perform resetting.
2. Safety sensor: Safety sensor is located in airbag ignition circuit. Safety sensor will operate airbag circuit at any deployment condition and release airbag circuit safely at normal driving condition. Safety sensor is a double contact electro-mechanical switch that will close detecting deceleration above certain criteria.
3. Back up power supply: SRSCM has separate back up power supply, that will supply deployment energy instantly in low voltage condition or upon power failure by front crash.
4. Self diagnosis: SRSCM will constantly monitor current SRS operation status and detect system failure while vehicle power supply is on, system failure may be checked with trouble codes using scan tool. (Hi-Scan)
5. Airbag warning lamp on: Upon detecting error, the module will transmit signal to SRSCM indicator lamp located at cluster. MIL lamp will indicate driver SRS error. Upon ignition key on, SRS lamp will turn on for about six seconds.
6. Trouble code registration: Upon error occurrence in system, SRSCM will store DTC corresponding to the error. DTC can be cleared only by Hi-Scan. However, if an internal fault code is logged or if a crash is recorded the fault clearing should not happen.
7. Self diagnostic connector: Data stored in SRSCM memory will be output to Hi-Scan or other external output devices through connector located below driver side crash pad.
8. Once airbag is deployed, SRSCM should not be used again but replaced.
9. SRSCM will determine whether passenger put on seat belt by the signal from built-in switch in seat belt buckle, and deploy front seat airbag at each set crash speed.
10. Side airbag deployment will be determined by SRSCM that will detect satellite sensor impact signal upon side crash, irrespective to seat belt condition.

GENERAL

RT -3





SPECIFICATION E89D783B

Item	Resistance ()
Driver Airbag (DAB)	1.6 ~ 6.4
Passenger Airbag (PAB)	1.8 ~ 6.4
Curtain Airbag (CAB)	1.8 ~ 4.8
Seat Belt Retractor Pretensioner (BPT)	1.8 ~ 6.4



TIGHTENING TORQUES EB73AFF1

Item	kgf·m	Nm	lb-ft
Driver Airbag (DAB)	0.8 ~ 1.1	7.9 ~ 10.8	5.8 ~ 8.0
Passenger Airbag (PAB)	Bolt : 1.9 ~ 2.7 Nut : 0.9 ~ 1.4	18.6 ~ 26.5 8.8 ~ 13.7	13.7 ~ 19.5 6.5 ~ 10.1
Curtain Airbag (CAB)	0.8 ~ 1.2	7.8 ~ 11.8	5.8 ~ 8.7
Seat Belt Anchor Bolt (BPT)	4.0 ~ 5.5	39.2 ~ 53.9	28.9 ~ 39.8
SRSCM Mounting Bolt	1.0 ~ 1.4	10.2 ~ 13.8	7.5 ~ 10.2
Front Impact Sensor (FIS) Mounting Bolt	1.0 ~ 1.4	10.2 ~ 13.8	7.5 ~ 10.2
Side Impact Sensor (SIS) Mounting Bolt	1.0 ~ 1.4	10.2 ~ 13.8	7.5 ~ 10.2

SPECIAL SERVICE TOOLS E37A38C8

Tool(Number and Name)	Illustration	Use
Deployment tool 0957A-34100A	 ARIE500A	Airbag deployment tool
Deployment adapter 0957A-3E110	 SBLRT6008D	Use with deployment tool. (PAB)
Deployment adapter 0957A-38500	 ARIE500C	Use with deployment tool. (DAB, CAB, BPT)
Dummy 0957A-38200	 ARIE500D	Simulator to check the resistance of each wiring harness

GENERAL

Tool(Number and Name)	Illustration	Use
Dummy adapter 0957A-3E100	 <small>SBLRT6009D</small>	Use with dummy (PAB)
Dummy adapter 0957A-2G000	 <small>ARIE500F</small>	Use with dummy (DAB, CAB, BPT)

DAB : Driver Airbag
PAB : Passenger Airbag
SAB : Side Airbag
CAB : Curtain Airbag
BPT : Seat Belt Retractor Pretensioner

PRECAUTIONS E915C2A3

GENERAL PRECAUTIONS


Please read the following precautions carefully before performing the airbag system service. Observe the instructions described in this manual, or the airbags could accidentally deploy and cause damage or injuries.

- Except when performing electrical inspections, always turn the ignition switch OFF and disconnect the negative cable from the battery, and wait at least three minutes before beginning work.

NOTE

The contents in the memory are not erased even if the ignition switch is turned OFF or the battery cables are disconnected from the battery.

- Use the replacement parts which are manufactured to the same standards as the original parts and quality. Do not install used SRS parts from another vehicle. Use only new parts when making SRS repairs.
- Carefully inspect any SRS part before you install it. Do not install any part that shows signs of being dropped or improperly handled, such as dents, cracks or deformation.



ERKD002V


- Before removing any of the SRS parts (including the disconnection of the connectors), always disconnect the SRS connector.

AIRBAG HANDLING AND STORAGE

Do not disassemble the airbags; it has no serviceable parts. Once an airbag has been deployed, it cannot be repaired or reused.

For temporary storage of the air bag during service, please observe the following precautions.

- Store the removed airbag with the pad surface up.
- Keep free from any oil, grease, detergent, or water to prevent damage to the airbag assembly.



ERKD002Z

- Store the removed airbag on secure, flat surface away from any high heat source (exceeding 85°C/185°F).
- Never perform electrical inspections to the airbags, such as measuring resistance.
- Do not position yourself in front of the airbag assembly during removal, inspection, or replacement.
- Refer to the scrapping procedures for disposal of the damaged airbag.
- Be careful not to bump or impact the SRS unit or the side impact sensors whenever the ignition switch is ON, wait at least three minutes after the ignition switch is turned OFF before begin work.
- During installation or replacement, be careful not to bump (by impact wrench, hammer, etc.) the area around the SRS unit and the side impact sensor. The airbags could accidentally deploy and cause damage or injury.
- After a collision in which the airbags were deployed, replace the front airbags and the SRS unit. After a collision in which the side airbag was deployed, replace the side airbag, the front impact sensor and side impact sensor on the side where the side airbag deployed and the SRS unit. After a collision in which the airbags or the side air bags did not deploy, inspect for any damage or any deformation on the SRS unit and


the side impact sensors. If there is any damage, replace the SRS unit, the front impact sensor and/or the side impact sensors.

- Do not disassemble the SRS unit, the front impact sensor or the side impact sensors
- Turn the ignition switch OFF, disconnect the battery negative cable and wait at least three minutes before beginning installation or replacement of the SRS unit.
- Be sure the SRS unit, the front impact sensor and side impact sensors are installed securely with the mounting bolts.
- Do not spill water or oil on the SRS unit, or the front impact sensor or the side impact sensors and keep them away from dust.
- Store the SRS unit, the front impact sensor and the side impact sensors in a cool (15 ~ 25 °C/59 ~ 77 °F) and dry (30% ~ 80%, no moisture) area.

WIRING PRECAUTIONS


SRS wiring can be identified by special yellow outer covering (except the SRS circuits under the front seats). Observe the instructions described in this section.

- Never attempt to modify, splice, or repair SRS wiring. If there is an open or damage in SRS wiring, replace the harness.



ERKD002Y

- Be sure to install the harness wires so that they are not pinched, or interfere with other parts.




ERKD002X

- Make sure all SRS ground locations are clean, and grounds are securely fastened for optimum metal-to-metal contact. Poor grounding can cause intermittent problems that are difficult to diagnose.

PRECAUTIONS FOR ELECTRICAL INSPECTIONS

- When using electrical test equipment, insert the probe of the tester into the wire side of the connector. Do not insert the probe of the tester into the terminal side of the connector, and do not tamper with the connector.



ERKD002W

- Use a u-shaped probe. Do not insert the probe forcibly.
- Use specified service connectors for troubleshooting.


Using improper tools could cause an error in inspection due to poor metal contact.

2. Lift up the connector inserting the driver underlay the connector body.


AIRBAG CONNECTOR(I)

DISCONNECTING


1. Remove the locking button using driver of connector to disconnect the connector.



SBLRT6032D




SBLRT6034D



SBLRT6033D


CONNECTING

1. Connect the connector body before inserting the locking button of connector.




SBLRT6035D

2. Press firmly the locking button of connector until the connector click to lock.



SBLRT6036D




SBLRT6032D

AIRBAG CONNECTOR(II)


DISCONNECTING

1. Pull the outside part of the connector in the direction of an arrow below.




SBLRT6037D

2. Disconnect the connector completely.




SBLRT6040D



SBLRT6038D


CONNECTING

1. Arrange the connectors for connection.




SBLRT6038D

2. Connect the connectors till occurring the sounds of locking completely in the direction of an arrow below.



SBLRT6039D



SBLRT6041D

WARNING LAMP ACTIVATION


E2B5F9DA

WARNING LAMP BEHAVIOR AFTER IGNITION ON

As soon as the operating voltage is applied to the SRSCM ignition input, the SRSCM activates the warning lamp for a bulb check.


The lamp shall turn on for 6 seconds during the initialization phase and be turned off afterward. However, in order to indicate the driver, the warning lamp shall turn on for 6 seconds and off for one second then on continuously after the operating voltage is applied if any active fault exists.

1. Active fault or historical fault counter is greater or equal to 10



BRIF500A

2. Normal or historical fault counter is less than 10



BRIF500B


SRSCM INDEPENDENT WARNING LAMP ACTIVATION

There are certain fault conditions in which the SRSCM cannot function and thus cannot control the operation of the standard warning lamp. In these cases, the standard warning lamp is directly activated by appropriate circuitry that operates independently of the SRSCM. These cases are:

1. Loss of battery supply to the SRSCM : warning lamp turned on continuously.
2. Loss of internal operating voltage : warning lamp turned on continuously.
3. Loss of Microprocessor operation : warning lamp turned on continuously.
4. SRSCM not connected : warning lamp turned on continuously through the shorting bar.

PASSENGER AIRBAG DEACTIVATION (PAD) LAMP OPERATION

The SRSCM is designed with circuitry and software to drive a PAD lamp, which is used for depowered airbag system. For the PAD indicator circuitry to function properly, both the SRSCM and PAD indicator are sourced from the same ignition line. After ignition on, the PAD indicator will be turned on for 4 seconds and off for 3 seconds during the initialization phase. Thereafter the lamp will be turned on as long as the PAD switch is in the disabled position.



ERRF501U

PASSENGER RESTRAINTS ACTIVATION WITH PAD SWITCH

The PAD switch affects the activation of the front passenger airbag only and the switch is controlled manually. The PAD switch will be functioned as follows:

PAD Switch status	PAD Lamp	PAB
Phase-up	ON OFF	Enabled
OFF	ON	Disabled
ON	OFF	Enabled
Fault	OFF	Enabled

COMPONENT REPLACEMENT AFTER DEPLOYMENT EA6E180C

NOTE

Before doing any SRS repairs, use the Hi-Scan Pro to check for DTCs. Refer to the Diagnostic Trouble Code list for repairing of the related DTCs.

When the front airbag(s) deployed after a collision, replace the following items.

- SRSCM
- Deployed airbag(s)
- Seat belt pretensioner(s)
- Front impact sensors
- SRS wiring harnesses
- Inspect the clock spring for heat damage. If any damage found, replace the clock spring.

When the seat belt pretensioner(s) deployed after a collision, replace the following items.

- Seat belt pretensioner(s)
- SRSCM (if B1658 detected)
- Front impact sensors
- SRS wiring harnesses


When the side/curtain airbag(s) deployed after a collision, replace the following items.

- SRSCM
- Deployed airbag(s)
- Side impact sensor(s) for the deployed side(s)
- SRS wiring harnesses

After the vehicle is completely repaired, confirm the SRS airbag system is OK.


- Turn the ignition switch ON, the SRS indicator should come on for about 6 seconds and then go off.

COMPONENTS E703CF82



- | | |
|---------------------------------|--|
| 1. Driver Airbag (DAB) | 7. Front Impact Sensor (FIS) |
| 2. Steering Wheel | 8. Curtain Airbag (CAB) |
| 3. Clock Spring | 9. Supplemental Restraint System Control Module(SRSCM) |
| 4. Seat Belt Pretensioner (BPT) | 10. Airbag Warning Lamp |
| 5. Side Impact Sensor (SIS) | 11. Passenger Airbag Deactivation (PAD) Lamp |
| 6. Passenger Airbag (PAB) | 12. PAD Switch |

SBLRT6100L




- | | |
|---------------------------------|---|
| 1. Driver Airbag (DAB) | 7. Front Impact Sensor (FIS) |
| 2. Steering Wheel | 8. Curtain Airbag (CAB) |
| 3. Clock Spring | 9. Supplemental Restraint System Control Module (SRSCM) |
| 4. Seat Belt Pretensioner (BPT) | 10. Airbag Warning Lamp |
| 5. Side Impact Sensor (SIS) | 11. Passenger Airbag Deactivation (PAD) Lamp |
| 6. Passenger Airbag (PAB) | 12. PAD Switch |

SBLRT6100R


COMPONENTS LOCATION

DRIVER AIRBAG (DAB) / PASSENGER AIRBAG (PAB)




SBLRT6101L

CURTAIN AIRBAG (CAB)




SBLRT6102L

SEAT BELT RETRACTOR PRETENSIONER (BPT)




SBLRT6103L

SUPPLEMENTAL RESTRAINT SYSTEM CONTROL MODULE (SRSCM)




SBLRT6001D

FRONT IMPACT SENSOR (FIS)



SBLRT6105L

SIDE IMPACT SENSOR (SIS)



SBLRT6106L

SUPPLEMENTAL RESTRAINT SYSTEM CONTROL MODULE(SRSCM)


SRS CONTROL MODULE

DESCRIPTION ECCF71AB

The primary purpose of the SRSCM (Supplemental Restraints System Control Module) is to discriminate between an event that warrants restraint system deployment and an event that does not. The SRSCM must decide whether to deploy the restraint system or not. After determining that pretensioners and/or airbag deployment is required, the SRSCM must supply sufficient power to the pretensioners and airbag igniters to initiate deployment.

The SRSCM determines that an impact may require deployment of the pretensioners and airbags from data obtained from impact sensors and other components in conjunction with a safing function. The SRSCM will not be ready to detect a crash or to activate the restraint system devices until the signals in the SRSCM circuitry stabilize. It is possible that the SRSCM could activate the safety restraint devices in approximately 2 seconds but is guaranteed to fully function after prove-out is completed. The SRSCM must perform a diagnostic routine and light a system readiness indicator at key-on. The system must perform a continuous diagnostic routine and provide fault annunciation through a warning lamp indicator in the event of fault detection. A serial diagnostic communication interface will be used to facilitate servicing of the restraint control system.


COMPONENTS EE414878



SBLRT6001D

REMOVAL E977543F

1. Remove the ignition key from the vehicle.
2. Disconnect the battery negative cable and wait for at least three minutes before beginning work.
3. Disconnect the DAB, PAB, CAB and BPT connectors.
4. Remove the floor console and heater ducts. (Refer to BD group)
5. Disconnect the SRSCM harness connector after pulling the connector locking lever.



SBLRT6002D

6. Remove the SRSCM mounting bolt (1EA) and nuts (2EA) from the SRSCM, then remove the SRSCM.

INSTALLATION E507F553

1. Remove the ignition key from the vehicle.
2. Disconnect the battery negative cable and wait for at least three minutes before beginning work.
3. Install the SRSCM with the SRSCM mounting bolt and nuts.

Tightening torque (SRSCM Mounting bolt)
: 1.0 ~ 1.4 kgf.m (10.2 ~ 13.8 Nm, 7.5 ~ 10.2 lb.ft)

 **NOTE**

Use new mounting bolts when replacing the SRSCM after a collision.

4. Connect the SRSCM harness connector completely with pushing the connector locking lever.
5. Install the heater ducts and floor console. (Refer to BD group)
6. Connect the DAB, PAB, CAB and BPT connectors.
7. Reconnect the battery negative cable.
8. After installing the SRSCM, confirm proper system operation:
 - Turn the ignition switch ON; the SRS indicator light should be turned on for about six seconds and then go off.

AIR BAG MODULE (DRIVER SIDE)

frontal crash occurs. The SRSCM determines deployment of Driver Airbag (DAB).

AIR BAG MODULE AND CLOCK SPRING


DESCRIPTION E19698E7

Driver Airbag (DAB) is installed in steering wheel and electrically connected to SRSCM via clockspring. It protects the driver from danger by deploying a bag when

CAUTION

Never attempt to measure the circuit resistance of the airbag module (squib) even if you are using the specified tester. If the circuit resistance is measured with a tester, accidental airbag deployment will result in serious personal injury.

COMPONENTS E0833290




- 1. Clock Spring
- 2. Steering Wheel

- 3. Driver Airbag (DAB)


REMOVAL E0450A67

1. Disconnect the battery negative cable and wait for at least three minutes before beginning work.
2. Remove the airbag module mounting bolts(2EA).



SBLRT6508D

3. Disconnect the horn connector(A).




SBLRT6007D

4. Release the connector locking pin, then disconnect the driver airbag module connector(B).

CAUTION


The removed airbag module should be stored in a clean, dry place with the pad cover face up.

5. Remove the steering wheel with SST (SST No. 09561-11001) after unfastening the mounting nut.




SBLRT6010D

6. Remove the steering wheel column cover after unscrewing 3 screws.



SBLRT6011D

7. Unscrew the clock spring tightening screws. (4EA)




SBLRT6012D

AIR BAG MODULE (DRIVER SIDE)

RT -21

8. Disconnect the clock spring wiring harness and the horn wiring harness connector from the clock spring.




SBLRT6013D

4. Check airbag inflator case for dents, cracks or deformities.



(Front view)



(Rear view)

SBLRT6509L

5. Install the airbag module to the steering wheel to check for fit or alignment with the wheel.

INSPECTION

E043119F

DRIVER AIRBAG (DAB)

If any improper parts are found during the following inspection, replace the airbag module with a new one.


CAUTION

Never attempt to measure the circuit resistance of the airbag module (squib) even if you are using the specified tester. If the circuit resistance is measured with a tester, accidental airbag deployment will result in serious personal injury.

1. Check pad cover for dents, cracks or deformities.
2. Check the airbag module for denting, cracking or deformation.
3. Check hooks and connectors for damage, terminals for deformities, and harness for binds.

CLOCKSPRING


1. If, as a result of the following checks, even one abnormal point is discovered, replace the clock spring with a new one.
2. Check connectors and protective tube for damage, and terminals for deformities.



SBLRT6015D

INSTALLATION EE7BDA1C

1. Remove the ignition key from the vehicle.
2. Disconnect the battery negative cable from battery and wait for at least three minutes before beginning work.
3. Connect the clock spring harness connector and horn harness connector to the clock spring.
4. Install the clock spring with 4 screws.
5. Set the center position by getting marks between the clock spring and the cover into line. Make an array the mark () by turning the clock spring clockwise to the stop and then 2.4 revolutions counterclockwise.




SBLRT6014D

6. Install the steering wheel column cover and the steering wheel. (Refer to ST group)
7. Connect the Driver Airbag (DAB) module connector and horn connector, then install the Driver Airbag (DAB) module on the steering wheel.

8. Secure the Driver Airbag (DAB) with the new mounting bolts.

Tightening torque (DAB Mounting Bolt)
: 0.8 ~ 1.1 kgf.m (7.9 ~ 10.8 Nm, 5.8 ~ 8.0 lb.ft)



SBLRT6508D

9. Connect the battery negative cable.
10. After installing the airbag, confirm proper system operation:
 - Turn the ignition switch ON; the SRS indicator light should be turned on for about six seconds and then go off.
 - Make sure horn button works.

AIR BAG MODULE (PASSENGER SIDE)

AIR BAG MODULE


DESCRIPTION E9593A37

The passenger Airbag (PAB) is installed inside the crash pad and protects the front passenger in the event of a frontal crash. The SRSCM determines if and when to deploy the PAB.

CAUTION

Never attempt to measure the circuit resistance of the airbag module (squib) even if you are using the specified tester. If the circuit resistance is measured with a tester, accidental airbag deployment will result in serious personal injury.


COMPONENTS EF548B7A



SBLRT6130L


REMOVAL E4EB22D1

1. Disconnect the battery negative cable and wait for at least three minutes before beginning work.
2. Remove the glove box. (Refer to BD group)
3. Remove the PAB mounting bolts (2EA).



SBLRT6017D

4. Disconnect the PAB module connector.



SBLRT6018D

5. Remove the crash pad. (Refer to BD group)

NOTE

If the crash pad is damaged when the PAB is deployed, replace the damaged crash pad and PAB together.

6. Remove the heater duct from the crash pad.
7. Remove the mounting nuts(6EA) from the crash pad. Then remove the passenger airbag.


CAUTION

The removed airbag module should be stored in a clean and dry place with the pad cover face up.

INSTALLATION E15B14BB

1. Remove the ignition key from the vehicle.
2. Disconnect the battery negative cable from battery and wait for at least three minutes before beginning work.
3. Place a Passenger Airbag (PAB) on the crash pad and tighten the Passenger Airbag (PAB) mounting nuts.

Tightening torque
: 0.9 ~ 1.4 kgf.m (8.8 ~ 13.7 N.m, 6.5 ~ 10.1 lb.ft)



SBLRT6019D

4. Install the heater duct to the crash pad.
5. Install the crash pad. (Refer to BD group)
6. Tighten the PAB mounting bolt.

Tightening torque
: 1.9 ~ 2.7 kgf.m (18.6 ~ 26.5 N.m, 13.7 ~ 19.5 lb.ft)

7. Connect the Passenger Airbag (PAB) harness connector to the SRS main harness connector.
8. Reinstall the glove box. (Refer to BD group)
9. Reconnect the battery negative cable.
10. After installing the Passenger Airbag (PAB), confirm proper system operation:
 - Turn the ignition switch ON; the SRS indicator light should be turned on for about six seconds and then go off.

AIR BAG MODULE (CURTAIN AIR BAG)

AIR BAG MODULE


DESCRIPTION EF7FBAD3

Curtain airbags are installed inside the headliner (LH and RH) and protect the driver and passenger from danger when side crash occurs. The SRSCM determines deployment of curtain airbag by using side impact sensor (SIS) signal.

CAUTION

Never attempt to measure the circuit resistance of the airbag module even if you are using the specified tester. If the circuit resistance is measured with a tester, accidental airbag deployment will result in serious personal injury.


COMPONENTS E4B3122F



SBLRT6102L


REMOVAL E41D5D56

1. Disconnect the battery negative cable and wait for at least 3 minutes before beginning work.
2. Remove the following parts. (Refer to BD group)
 - Side trim, Roof trim
3. Disconnect the Curtain Airbag harness connector.



SBLRT6004D

4. After loosening the mounting bolts(6EA) and nut (1EA) remove the curtain airbag.



SBLRT6511D

INSTALLATION E50B5670

1. Remove the ignition key from the vehicle.
2. Disconnect the battery negative cable and wait for at least three minutes.
3. Install a Curtain Airbag (CAB) on the mounting bracket.
4. Tighten the CAB mounting bolts (6EA) and nut (1EA).

Tightening torque
: 0.8 ~ 1.2 kgf.m(7.8 ~ 11.8 Nm, 5.8 ~ 8.7 lb.ft)

CAUTION

- **Never twist the airbag module when installing it. If the module is twisted, airbag module may operate abnormally.**

5. Connect the CAB connector.
6. Install the following parts. (Refer to BD group)
 - Side trim, Roof trim
7. Reconnect the battery negative cable.
8. After installing the Curtain Airbag (CAB), confirm proper system operation:
 - Turn the ignition switch ON; the SRS indicator light should be turned on for about six seconds and then go off.

SEAT BELT PRETENSIONER

SEAT BELT PRETENSIONER

DESCRIPTION E4167EBA


The Seat Belt Pretensioners (BPT) are installed inside Center Pillar (LH & RH). When a vehicle crashes with a certain degree of frontal impact, the pretensioner seat belt helps to reduce the severity of injury to the front seat occupants by retracting the seat belt webbing. This prevents the front occupants from thrusting forward and hitting the

steering wheel or the instrument panel when the vehicle crashes.

CAUTION

Never attempt to measure the circuit resistance of the Seat Belt Pretensioner (BPT) even if you are using the specified tester. If the circuit resistance is measured with a tester, the pretensioner will be ignited accidentally. This will result in serious personal injury.


COMPONENTS E13C3CFE



SBLRT6103L


REMOVAL E3B165BB

1. Disconnect the battery negative cable, and wait for at least three minutes before beginning work.
2. Remove the lower anchor bolt.




SBLRT6022D

3. Remove the following parts. (Refer to BD group)
 - Door scuff trim, Center pillar trim
4. Remove the upper anchor bolt.
5. Disconnect the Seat Belt Pretensioner connector.



SBLRT6024D

6. Loosen the Seat Belt Pretensioner mounting bolt and remove the Seat Belt Pretensioner.



SBLRT6532D

INSTALLATION E3B35607

1. Remove the ignition key from the vehicle.
2. Disconnect the battery negative cable and wait for at least three minutes.
3. Install the Seat Belt Pretensioner (BPT) with a bolt.

Tightening torque
: 4.0 ~ 5.5 kgf.m (39.2 ~ 53.9 Nm, 28.9 ~ 39.8 lb.ft)

4. Connect the Seat Belt Pretentioner (BPT) connector.
5. Install the upper anchor bolts.

Tightening torque (Seat Belt Anchor Bolt)
: 4.0 ~ 5.5 kgf.m (39.2 ~ 53.9 Nm, 28.9 ~ 39.8 lb.ft)

6. Install the center pillar trim.
7. Install the door scuff trim.
8. Install the lower anchor bolt.
9. Reconnect the battery negative cable.
10. After installing the Seat Belt Pretensioner (BPT), confirm proper system operation:
 - Turn the ignition switch ON; the SRS indicator light should be turned on for about six seconds and then go off.

SRS CONTROL SYSTEM


FRONT IMPACT SENSOR (FIS)

to a collision at its mounting location. The primary purpose of the Front Impact Sensor (FIS) is to provide an indication of a collision. The Front Impact Sensor(FIS) sends acceleration data to the SRSCM.

DESCRIPTION EBEE040F

The front impact sensor (FIS) is installed in the side member. They are remote sensors that detect acceleration due

COMPONENTS E603A5DC




SBLRT6105L

REMOVAL EDE19F4F

CAUTION

- **Removal of the airbag must be performed according to the precautions/ procedures described previously.**
- **Before disconnecting the front impact sensor connector, disconnect the front airbag connector(s).**
- **Do not turn the ignition switch ON and do not connect the battery cable while replacing the front impact sensor.**

1. Disconnect the battery negative cable, and wait for at least three minutes before beginning work.
2. Remove the Front bumper. (Refer to BD group)
3. Remove the Front Impact Sensor mounting bolt.



SBLRT6026D

4. Disconnect the Front Impact Sensor connector.

INSTALLATION E50C4826

CAUTION

- **Do not turn the ignition switch ON and do not contact the battery cable while replacing the front impact sensor.**

1. Install the new Front Impact Sensor.
2. Tighten the Front Impact Sensor mounting bolt.

Tightening torque
: 1.0 ~ 1.4 kgf.m (10.2 ~ 13.8 Nm, 7.5 ~ 10.2 lb.ft)

3. Connect the Front Impact Sensor connector.
4. Install the front bumper. (Refer to BD group)
5. Reconnect the battery negative cable.
6. After installing the Front Impact Sensor, confirm proper system operation: Turn the ignition switch ON the SRS indicator light should be turned on for about six seconds and then go off.


SIDE IMPACT SENSOR (SIS)

DESCRIPTION E49F823B

The Side Impact Sensor (SIS) system consists of two front SIS which are installed in the center pillar (LH and RH) They are remote sensors that detect acceleration due to

collision at their mounting locations. The primary purpose of the Side Impact Sensor (SIS) is to provide an indication of a collision. The Side Impact Sensor (SIS) sends acceleration data to the SRSCM.

COMPONENTS E86DACC B




SBLRT6106L

REMOVAL E34BD0EF

CAUTION


- **Removal of the airbag must be performed according to the precautions/procedures described previously.**
- **Before disconnecting the side impact sensor connector(s), disconnect the side airbag connector(s).**
- **Do not turn the ignition switch ON and do not connect the battery cable while replacing the side impact sensor.**

1. Disconnect the battery negative cable, and wait for at least three minutes before beginning work.
2. Remove the lower anchor bolt.



SBLRT6022D

3. Remove the following parts. (Refer to BD group)
 - Door scuff trim, Center pillar trim
4. Disconnect the Side Impact Sensor connector and remove the Side Impact Sensor mounting bolt.



SBLRT6522D

INSTALLATION E88CF110

CAUTION

- **Do not turn the ignition switch ON and do not connect the battery cable while replacing the side impact sensor.**

1. Install the new Side Impact Sensor with the bolt then connect the SRS harness connector to the Side Impact Sensor.

Tightening torque
: 1.0 ~ 1.4 kgf.m (10.2 ~ 13.8 Nm, 7.5 ~ 10.2 lb.ft)


2. Install the center pillar trim. (Refer to BD group)
3. Install the door scuff trim. (Refer to BD group)
4. Install the lower anchor bolt.
5. Reconnect the battery negative cable.
6. After installing the Side Impact Sensor, confirm proper system operation: Turn the ignition switch ON, the SRS indicator light should be turned on for about six seconds and then go off.

TROUBLESHOOTING

DESCRIPTION E24ED7B0

HI-SCAN CHECK


1. Turn the ignition switch off.
2. Connect the Hi-Scan Pro connector to the data link connector located under the crash pad.



SBLRT6899D

3. Turn the ignition switch on and power on the Hi-Scan Pro.
4. Read DTCs.
5. Find and repair the trouble, and clear the DTCs using Hi-Scan Pro.
6. Disconnect the Hi-Scan Pro.
7. Confirm proper system operation ;
 - Turn the ignition switch ON; the SRS indicator light should be turned on for about six seconds and then go off.

DIAGNOSTIC TROUBLESHOOTING FLOW



ERA9035A

TERMINAL & CONNECTOR INSPECTION

Be sure to perform "TERMINAL & CONNECTOR INSPECTION" before doing "INSPECTION PROCEDURE" for troubleshooting of each DTC.

1. Visually inspect all connectors related to the affected circuit for damage and secure connection.
2. Inspect terminals for damage and corrosion.



Avoid damaging connectors during the inspection process.

3. Are any problems found?

NO

Go to next step (INSPECTION PROCEDURE).

YES

After repairing the trouble part, check whether DTC occurs or not.

PREPARATION OF INSPECTION

Refer to the following steps while doing "INSPECTION PROCEDURE" which is described in the DTC troubleshooting section.

1. Turn the ignition switch to LOCK.
2. Disconnect the battery negative cable from the battery and wait for at least 3 minutes.
3. Remove the DAB module and disconnect the DAB connector.
4. Disconnect the connectors of the PAB, CAB, BPT, FIS and SIS.
5. Disconnect the SRSCM connector.

CHECKING OF SHORT OR OPEN CIRCUIT

Refer to the following tips for checking of short or open circuit.

1. Shorting bar is located on the upper side of pin number from 2 to 25 of SRSCM connector.

2. When checking the short circuit shorting bar must be opened. Use a plastic clip to put into as a shorting bar opener for disconnecting shorting bar.
3. Use SST Dummy adapter (0957A-2G000) to measure resistance or voltage for checking of short or open circuit. Plug it into DAB (BPT) connector to avoid enlarging or damaging the connector pins.

CLEAR THE DTC AND CHECK THE VEHICLE AGAIN

1. Install the DAB module and connect the DAB connector.
2. Connect the connector of the PAB, CAB, BPT, FIS and SIS.
3. Connect the SRSCM connector.
4. Connect the battery negative cable to the battery.
5. Connect a Hi-Scan(Pro) to the data link connector.
6. Turn the ignition switch to ON.
7. Clear the DTC stored in the SRSCM memory with the Hi-Scan(Pro)
8. Turn the ignition switch to LOCK and wait for at least 30 seconds.
9. Turn the ignition switch to ON and wait for at least 30 seconds.
10. Check the vehicle again with the Hi-Scan(Pro). Does the above DTC(s) go off?

YES


Problem is intermittent or was repaired and SRSCM memory was not cleared.

NO


Replace the SRSCM with a new one and then check the vehicle again. At this time, if the vehicle normally operates with a new one, the fault may be the SRSCM. Replace the SRSCM.

CIRCUIT DIAGRAM

E4BAAC09




SBLRT6200L



SBLRT6201L

SRSCM CONNECTOR TERMINAL E72E8805



Shorting bar (○) : located on the upper side of pin number from 2 to 25 of SRSCM connector.

Note : For short circuit check, shorting bar must be opened. Use a plastic clip as a shorting bar opener for disconnecting shorting bar.

Pin	Function	Pin	Function
1	-	50	-
2~25	Shorting Bar	51	-
26	Ignition	52	-
27	Airbag Warning Lamp	53	-
28	Power Ground	54	K-Line Diagnostic
29	Driver Airbag Low	55	-
30	Driver Airbag High	56	PAB off Lamp
31	Passenger Airbag High	57	-
32	Passenger Airbag Low	58	Crash Output
33	Seat Belt Pretensioner [Driver] Low	59	-
34	Seat Belt Pretensioner [Driver] High	60	PAD Switch
35	Seat Belt Pretensioner [Passenger] High	61	-
36	Seat Belt Pretensioner [Passenger] Low	62	-
37	Curtain Airbag [Driver] Low	63	-
38	Curtain Airbag [Driver] High	64	-
39	Curtain Airbag [Passenger] High	65	-
40	Curtain Airbag [Passenger] Low	66	-
41	-	67	-
42	-	68	Side Impact Sensor [Passenger] Low
43	-	69	Side Impact Sensor [Passenger] High
44	-	70	Side Impact Sensor [Driver] High
45	-	71	Side Impact Sensor [Driver] Low
46	-	72	Front Impact Sensor [Passenger] Low
47	-	73	Front Impact Sensor [Passenger] High
48	-	74	Front Impact Sensor [Driver] High
49	-	75	Front Impact Sensor [Driver] Low

DIAGNOSTIC TROUBLE CODES (DTC)

DTC	FAULT DESCRIPTION	REMARK
B1101	Battery Voltage High	RT - 41
B1102	Battery Voltage Low	RT - 41
B1103	Communication Voltage too Low	RT - 41
B1326	Front Impact Sensor [Driver] Short to Ground	RT - 44
B1327	Front Impact Sensor [Driver] Short to Battery	RT - 46
B1328	Front Impact Sensor [Driver] Defect	RT - 48
B1329	Front Impact Sensor [Driver] Communication Error	RT - 48
B1330	Front Impact Sensor [Driver] Wrong ID	RT - 51
B1331	Front Impact Sensor [Passenger] Short to Ground	RT - 44
B1332	Front Impact Sensor [Passenger] Short to Battery	RT - 46
B1333	Front Impact Sensor [Passenger] Defect	RT - 48
B1334	Front Impact Sensor [Passenger] Communication Error	RT - 48
B1335	Front Impact Sensor [Passenger] Wrong ID	RT - 51
B1346	Driver Airbag Resistance too High	RT - 52
B1347	Driver Airbag Resistance too Low	RT - 52
B1348	Driver Airbag Circuit Short to Ground	RT - 55
B1349	Driver Airbag Circuit Short to Battery	RT - 58
B1352	Passenger Airbag Resistance too High	RT - 61
B1353	Passenger Airbag Resistance too Low	RT - 61
B1354	Passenger Airbag Circuit Short to Ground	RT - 64
B1355	Passenger Airbag Circuit Short to Battery	RT - 66
B1361	Seat Belt Pretensioner [Front-Driver] Resistance too High	RT - 68
B1362	Seat Belt Pretensioner [Front-Driver] Resistance too Low	RT - 68
B1363	Seat Belt Pretensioner [Front-Driver] Circuit Short to Ground	RT - 71
B1364	Seat Belt Pretensioner [Front-Driver] Circuit Short to Battery	RT - 73
B1367	Seat Belt Pretensioner [Front-Passenger] Resistance too High	RT - 68
B1368	Seat Belt Pretensioner [Front-Passenger] Resistance too Low	RT - 68
B1369	Seat Belt Pretensioner [Front-Passenger] Circuit Short to Ground	RT - 71
B1370	Seat Belt Pretensioner [Front-Passenger] Circuit Short to Battery	RT - 73
B1395	Squib Interconnection Fault	RT - 76
B1400	Side Impact Sensor [Front-Driver] Defect	RT - 77
B1401	Side Impact Sensor [Front-Driver] Short to Ground	RT - 80
B1402	Side Impact Sensor [Front-Driver] Short to Battery	RT - 82
B1403	Side Impact Sensor [Front-Passenger] Defect	RT - 77
B1404	Side Impact Sensor [Front-Passenger] Short to Ground	RT - 80
B1405	Side Impact Sensor [Front-Passenger] Short to Battery	RT - 82
B1409	Side Impact Sensor [Front-Driver] Communication Error	RT - 77

RT -40

RESTRAINTS

DTC	FAULT DESCRIPTION	REMARK
B1410	Side Impact Sensor [Front-Passenger] Communication Error	RT - 77
B1414	Side Impact Sensor [Front-Driver] Wrong ID	RT - 84
B1415	Side Impact Sensor [Front-Passenger] Wrong ID	RT - 84
B1473	Curtain Airbag [Driver] Resistance too High	RT - 85
B1474	Curtain Airbag [Driver] Resistance too Low	RT - 85
B1475	Curtain Airbag [Driver] Circuit Short to Ground	RT - 89
B1476	Curtain Airbag [Driver] Circuit Short to Battery	RT - 91
B1477	Curtain Airbag [Passenger] Resistance too High	RT - 85
B1478	Curtain Airbag [Passenger] Resistance too Low	RT - 85
B1479	Curtain Airbag [Passenger] Circuit Short to Ground	RT - 89
B1480	Curtain Airbag [Passenger] Circuit Short to Battery	RT - 91
B1527	Passenger Airbag Deactivation Switch Open or Short to Battery	RT - 94
B1528	Passenger Airbag Deactivation Switch Short or Short to Ground	RT - 98
B1529	Passenger Airbag Deactivation Switch Defect	RT - 101
B1620	Supplemental Restraint System Control Module Internal Fault (Replace SRSCM)	RT - 105
B1650	Crash Recorded - Frontal (Replace SRSCM)	RT - 106
B1651	Crash Recorded - Driver Side (Replace SRSCM)	RT - 106
B1652	Crash Recorded - Passenger Side (Replace SRSCM)	RT - 106
B1657	Crash Recorded - Belt Pretensioner Only	RT - 106
B1658	Belt Pretensioner 6 times Deployment (Replace SRSCM)	RT - 106
B2500	Warning Lamp Fault	RT - 107
B2505	Passenger Airbag Deactivation Lamp Fault	RT - 111

DTC B1101 BATTERY VOLTAGE TOO HIGH
DTC B1102 BATTERY VOLTAGE TOO LOW
DTC B1103 COMMUNICATION VOLTAGE LOW


DTC DESCRIPTION E0263EC0

The SRSCM sets above DTC(s) if it detects that the battery voltage of restraints system is too high or too low. When the voltage returns to normal, the SRS warning light automatically goes off and a malfunction is no longer indicated. The SRSCM can communicate with outside equipment as Front Impact Sensor (FIS), Side Impact Sensor (SIS) when battery voltage is 10.6 V or above. The SRSCM sets B1103 code if it detects their malfunction through mounting outside equipments continuously when battery voltage is 10.6V below.

DTC DETECTING CONDITION E02CF8F9

DTC	Condition	Probable cause
B1101	Battery Voltage > 16.5 V for 4 seconds after IG ON	<ul style="list-style-type: none"> • Battery • Generator • Wiring Harness • SRSCM
B1102	Battery Voltage < 10.6 V for 4 seconds after IG ON	
B1103	Battery Voltage < 10.6 V for 4 seconds after IG ON The malfunction of the restraints system outside equipment	

SCHEMATIC DIAGRAM E460A1C6



SBLRT6210L

SPECIFICATION E43DFADC

Voltage : 10.6 ~ 16.5 V

TERMINAL & CONNECTOR INSPECTION EC4827F3

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE EA28265C


1. PREPARATION

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

2. CHECK SOURCE VOLTAGE

- 1) Turn the ignition switch to ON.
- 2) Measure voltage between the terminal 26 of SRSCM harness connector and chassis ground.

Specification (voltage) : 10.6 ~ 16.5 V



SBLRT6211L

3) Is the measured voltage within specification?

NO

Check the battery.

YES

Replace the SRSCM with a new one, and then check the vehicle again. At this time, if the vehicle normally operates with a new SRSCM, the fault may be the SRSCM(Replace SRSCM).

3. CHECK THE BATTERY

1) Check the battery.

Refer to "EE" group in this SERVICE MANUAL.
Is the battery normal?

YES

Check the generator.

NO

Repair or replace the battery.(Refer to "EE" group in this SERVICE MANUAL)

4. CHECK GENERATOR

- 1) Check the generator.
Refer to "EE" group in this SERVICE MANUAL.
Is the generator normal?

YES

Check wiring harness.

NO

Repair or replace the generator.(Refer to "EE" group in this SERVICE MANUAL)

5. CHECK WIRING HARNESS

- 1) Check the wiring harness between the battery and SRSCM.
Is the wiring harness normal?

YES

Check the DTC again.

NO

Repair or Replace the wiring harness.

6. CHECK THE DTC AGAIN

- 1) Turn the ignition switch to LOCK and wait for at least 30 seconds.



CAUTION

Check again that the battery negative cable is disconnected from the battery.

- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.
- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC?

YES

Perform the troubleshooting procedures associated with those codes.


NO

Problem is intermittent or was repaired and SRSCM memory was not cleared.

2. CHECK FIS CIRCUIT

- 1) Measure resistance between the terminal 1 of FIS harness connector and chassis ground.

specification(resistance) :



SBLRT6221L

- 2) Is the measured resistance within specification?

YES

Check Front Impact Sensor.

NO

Repair or replace the wiring harness between the FIS and the SRSCM.

3. CHECK FRONT IMPACT SENSOR

- 1) Replace the front impact sensor(FIS) with a new one.
Refer to "Front Impact Sensor(FIS)" section in this SERVICE MANUAL.
- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.
- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC related to FIS?

YES

Go to next step.

NO

Replace the Front Impact Sensor(FIS).

4. CLEAR THE DTC AND CHECK THE DTC AGAIN

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

DTC B1327 FRONT IMPACT SENSOR [DRIVER] SHORT TO BATTERY
DTC B1332 FRONT IMPACT SENSOR [PASSENGER] SHORT TO BATTERY


DTC DESCRIPTION ECF62D8B

The detecting system for front crash consists of the SRSCM and two Front Impact Sensors (FIS). The SRSCM sets above DTC(s) if it detects short to battery on the FIS circuit.

DTC DETECTING CONDITION EBBDEFA3

DTC	Condition	Probable cause
B1327 B1332	<ul style="list-style-type: none"> Short to battery line between FIS and SRSCM Front Impact Sensor(FIS) Malfunction SRSCM Malfunction 	<ul style="list-style-type: none"> Short to battery line on Wiring Harness Front Impact Sensor(FIS) SRSCM

SCHEMATIC DIAGRAM EC734759



SBLRT6220L

TERMINAL & CONNECTOR INSPECTION E283653D

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE E29FB001


1. PREPARATION
Refer to the DESCRIPTION in this TROUBLESHOOTING section.
2. CHECK FIS CIRCUIT

TROUBLESHOOTING

RT -47

- 1) Connect the battery negative cable to the battery.
- 2) Turn the ignition switch to ON.
- 3) Measure voltage between the terminal 1 of FIS harness connector and chassis ground.

specification(voltage) : Approximately 0 V



SBLRT6222L

- 4) Is the measured voltage within specification?

YES

Check Front Impact Sensor.

NO

Repair the short to battery line circuit on wiring harness between the FIS and the SRSCM.

3. CHECK FRONT IMPACT SENSOR

- 1) Replace the front impact sensor(FIS) with a new one.
Refer to "Front Impact Sensor(FIS)" section in this SERVICE MANUAL.
- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.
- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC related to FIS?

YES

Go to next step.

NO

Replace the Front Impact Sensor(FIS).

4. CLEAR THE DTC AND CHECK THE DTC AGAIN

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE

EB342E09


1. PREPARATION

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

2. CHECK FIS CIRCUIT

- 1) Measure resistance between the terminal 1 of FIS harness connector and the terminal 74(73) of SRSCM harness connector.
- 2) Measure resistance between the terminal 2 of FIS harness connector and the terminal 75(72) of SRSCM harness connector.

Specification (resistance) : below 1



SBLRT6223L

- 3) Is the measured resistance within specification?

YES

Check Front Impact Sensor.

NO

Repair or replace the wiring harness between the FIS and the SRSCM.

3. CHECK FRONT IMPACT SENSOR

- 1) Replace the front impact sensor(FIS) with a new one.
Refer to "Front Impact Sensor(FIS)" section in this SERVICE MANUAL.
- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.

- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC related to FIS?

YES

Go to next step.

NO

Replace the Front Impact Sensor(FIS).

4. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN
Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE EBC88CD3


1. PREPARATION
Refer to the DESCRIPTION in this TROUBLESHOOTING section.
2. CHECK DAB RESISTANCE

 **CAUTION**

Never attempt to measure the circuit resistance of the airbag module(squib) even if you are using the specified tester.

- 1) Connect the Dummy and the Dummy Adapter on DAB harness connector.
Refer to "SPECIAL SERVICE TOOL" section in this SERVICE MANUAL for the SST No. of Dummy and Dummy Adapter.
- 2) Measure resistance between the terminal 30 and 29 of SRSCM harness connector.

Specification (resistance) : 1.6 ~ 6.4



SBLRT6231L

- 3) Is the measured resistance within specification?

NO

Check open circuit.


YES

Replace the Driver Airbag(DAB) module.

3. CHECK OPEN CIRCUIT

- 1) Measure resistance between the terminal 1 of DAB harness connector and the terminal 30 of SRSCM harness connector.
- 2) Measure resistance between the terminal 2 of DAB harness connector and the terminal 29 of SRSCM harness connector.

Specification (resistance) : below 1



SBLRT6232L

3) Is the measured resistance within specification?

YES

Check short circuit.


NO

Repair or replace the wiring harness between the DAB and the clockspring or between the clockspring and the SRSCM.

4. CHECK SHORT CIRCUIT

1) Measure resistance between the terminal 1 and 2 of DAB harness connector.

Specification (resistance) :



SBLRT6233L

2) Is the measured resistance within specification?

YES

Go to next step.

NO

Repair or replace the wiring harness between the DAB and the clockspring or between the clockspring and the SRSCM.

5. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

DTC B1348 DRIVER AIRBAG RESISTANCE CIRCUIT SHORT TO GROUND


DTC DESCRIPTION E8857516

The Driver Airbag circuit consists of the SRSCM, Clockspring and the Driver Airbag (DAB). The SRSCM sets above DTC(s) if it detects short to ground on the DAB circuit.

DTC DETECTING CONDITION EDEAA31B

DTC	Condition	Probable cause
B1348	<ul style="list-style-type: none"> • Short to ground between DAB and clockspring • Short to ground between clockspring and SRSCM • Driver Airbag (DAB) Malfunction • Clockspring Malfunction • SRSCM Malfunction 	<ul style="list-style-type: none"> • Short to ground circuit on wiring harness • Driver Airbag (DAB) squib • Clockspring • SRSCM

SCHEMATIC DIAGRAM E7452174



SBLRT6230L

TERMINAL & CONNECTOR INSPECTION EF24FC93

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE

E8231ED6


1. PREPARATION

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

2. CHECK SHORT TO GROUND

- 1) Measure resistance between the terminal 1 of DAB harness connector and chassis ground.

Specification (resistance) : infinite



SBLRT6234L

- 2) Is the measured resistance within specification?

YES

Check the DAB Module.

NO

Repair or replace the wiring harness between the DAB and the clockspring or between the clockspring and the SRSCM.

3. CHECK THE DAB MODULE

- 1) Replace the Driver Airbag(DAB) with a new one.
Refer to "Driver Airbag(DAB)" section in this SERVICE MANUAL.
- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.

- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC related to DAB?

YES

Check the clockspring.

NO

Replace the Driver Airbag(DAB).

4. CHECK THE CLOCKSPRING

- 1) Check the clockspring.
Is the clockspring normal?

YES

Go to next step.

NO

Replace the clockspring.

5. **CLEAR THE DTC AND CHECK THE VEHICLE AGAIN**
Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE ECBB0522


1. PREPARATION

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

2. CHECK SHORT TO BATTERY LINE

- 1) Connect the battery negative cable to the battery.
- 2) Turn the ignition switch to ON.
- 3) Measure voltage between the terminal 1 of DAB harness connector and chassis ground.

Specification (voltage) : Approximately 0 V



SBLRT6235L

4) Is the measured voltage within specification?

YES

Check the DAB module.

NO

Repair or replace the wiring harness between the DAB and the clockspring or between the clockspring and the SRSCM.

3. CHECK THE DAB MODULE

- 1) Replace the Driver Airbag(DAB) with a new one.
Refer to "Driver Airbag(DAB)" section in this SERVICE MANUAL.
- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.

- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC related to DAB?

YES

Check the clockspring.

NO

Replace the Driver Airbag(DAB).

4. CHECK THE CLOCKSPRING

- 1) Check the clockspring.
Is the clockspring normal?

YES

Go to next step.

NO

Replace the clockspring.

5. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN
Refer to the DESCRIPTION in this TROUBLESHOOTING section.

TROUBLESHOOTING

RT -61

**DTC B1352 PASSENGER AIRBAG RESISTANCE TOO HIGH
DTC B1353 PASSENGER AIRBAG RESISTANCE TOO LOW**


DTC DESCRIPTION EFA671A4

The Passenger Airbag circuit consists of the SRSCM and the Passenger Airbag (PAB). The SRSCM sets above DTC(s) if it detects that the resistance of PAB squib is too high or low.

DTC DETECTING CONDITION E71070B2

DTC	Condition	Probable cause
B1352 B1353	<ul style="list-style-type: none"> • Too high or low resistance between PAB high(+) and PAB low (-) • Passenger Airbag (PAB) Malfunction • SRSCM Malfunction 	<ul style="list-style-type: none"> • Open or short circuit on wiring harness • Passenger Airbag (PAB) squib • SRSCM

SCHEMATIC DIAGRAM E00881BB



SBLRT6240L

SPECIFICATION E69C3EA8

PAB resistance : 1.8 ~ 6.4

TERMINAL & CONNECTOR INSPECTION E1DCF032

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE

E8418581


1. PREPARATION
Refer to the DESCRIPTION in this TROUBLESHOOTING section.
2. CHECK PAB RESISTANCE

CAUTION

Never attempt to measure the circuit resistance of the airbag module(squib) even if you are using the specified tester.

- 1) Connect the Dummy and the Dummy Adapter on PAB harness connector.
Refer to "SPECIAL SERVICE TOOL" section in this SERVICE MANUAL for the SST No. of Dummy and Dummy Adapter.
- 2) Measure resistance between the terminal 32 and 31 of SRSCM harness connector.

Specification (resistance) : 1.8 ~ 6.4



SBLRT6241L

- 3) Is the measured resistance within specification?

YES

Replace the Passenger Airbag(PAB) module.


NO

Check open circuit.

3. CHECK OPEN CIRCUIT

- 1) Measure resistance between the terminal 1 of PAB harness connector and the terminal 32 of SRSCM harness connector.
- 2) Measure resistance between the terminal 2 of PAB harness connector and the terminal 31 of SRSCM harness connector.

Specification (resistance) : below 1



SBLRT6242L

3) Is the measured resistance within specification?

YES

Check short circuit.


NO

Repair or replace the wiring harness between the PAB and the SRSCM.

4. CHECK SHORT CIRCUIT

1) Measure resistance between the terminal 1 and 2 of PAB harness connector.

Specification (resistance) : infinite



SBLRT6243L

2) Is the measured resistance within specification?

YES

Go to next step.

NO

Repair or replace the wiring harness between the PAB and the SRSCM.


5. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

2. CHECK SHORT TO GROUND

- 1) Measure resistance between the terminal 2 of PAB harness connector and chassis ground.

Specification (resistance) : infinite



SBLRT6244L

- 2) Is the measured resistance within specification?

YES

Check the PAB Module.

NO

Repair or replace the wiring harness between the PAB and the SRSCM.

3. CHECK THE PAB MODULE

- 1) Replace the Passenger Airbag (PAB) with a new one.
Refer to "Passenger Airbag (PAB)" section in this SERVICE MANUAL.
- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.
- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC related to PAB?

YES

Go to next step.

NO

Replace PAB module.

4. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

DTC B1355 PASSENGER AIRBAG CIRCUIT SHORT TO BATTERY


DTC DESCRIPTION E9F54B5F

The Passenger Airbag circuit consists of the SRSCM and the Passenger Airbag (PAB). The SRSCM sets above DTC(s) if it detects short to battery line on the PAB circuit.

DTC DETECTING CONDITION E9D89E39

DTC	Condition	Probable cause
B1355	<ul style="list-style-type: none"> Short to battery line between PAB and SRSCM Passenger Airbag (PAB) Malfunction SRSCM Malfunction 	<ul style="list-style-type: none"> Short to battery line circuit on wiring harness Passenger Airbag (PAB) squib SRSCM

SCHEMATIC DIAGRAM E2FEC588



SBLRT6240L

TERMINAL & CONNECTOR INSPECTION EC5A213D


Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE EBF2C8C7

- PREPARATION
Refer to the DESCRIPTION in this TROUBLESHOOTING section.
- CHECK SHORT TO BATTERY LINE
 - Connect the battery negative cable to the battery.
 - Turn the ignition switch to ON.

- 3) Measure voltage between the terminal 2 of PAB harness connector and chassis ground.

Specification (voltage) : Approximately 0 V



SBLRT6245L

- 4) Is the measured voltage within specification?

YES

Check the PAB Module.

NO

Repair the short to battery line circuit on wiring harness between the PAB and the SRSCM.

3. CHECK THE PAB MODULE

- 1) Replace the Passenger Airbag(PAB) with a new one.
Refer to "Passenger Airbag(PAB)" section in this SERVICE MANUAL.
- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.
- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC related to PAB?

YES

Go to next step.

NO

Replace PAB module.

4. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN
Refer to the DESCRIPTION in this TROUBLESHOOTING section.

TERMINAL & CONNECTOR INSPECTION E26841C2

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE E0EB316D


1. PREPARATION
Refer to the DESCRIPTION in this TROUBLESHOOTING section.
2. CHECK BPT RESISTANCE

⚠ CAUTION

Never attempt to measure the circuit resistance of the airbag module(squib) even if you are using the specified tester.

- 1) Connect the Dummy and the Dummy Adapter on BPT harness connector.
Refer to "SPECIAL SERVICE TOOL" section in this SERVICE MANUAL for the SST No. of Dummy and Dummy Adapter.
- 2) Measure resistance between the terminal 34(35) and 33(36) of SRSCM harness connector.

Specification (resistance) : 1.8 ~ 6.4



SBLRT6251L

- 3) Is the measured resistance within specification?

YES

Replace the Seat Belt Pretensioner(BPT) module.


NO

Check open circuit.

3. CHECK OPEN CIRCUIT

- 1) Measure resistance between the terminal 1(2) of BPT harness connector and the terminal 34(35) of SRSCM harness connector.
- 2) Measure resistance between the terminal 2(1) of BPT harness connector and the terminal 33(36) of SRSCM harness connector.

Specification (resistance) : below 1



SBLRT6252L

3) Is the measured resistance within specification?

YES

Check short circuit.


NO

Repair or replace the wiring harness between the BPT and the SRSCM.

4. CHECK SHORT CIRCUIT

1) Measure resistance between the terminal 1(2) and 2(1) of BPT harness connector.

Specification (resistance) : infinite



SBLRT6253L

2) Is the measured resistance within specification?

YES

Go to next step.

NO

Repair or replace the wiring harness between the BPT and the SRSCM.

5. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

TROUBLESHOOTING

**DTC B1363 SEAT BELT PRETENSIONER [FRONT-DRIVER]
CIRCUIT SHORT TO GROUND**
**DTC B1369 SEAT BELT PRETENSIONER [FRONT-PASSENGER]
CIRCUIT SHORT TO GROUND**


DTC DESCRIPTION E424B2CF

The Seat Belt Pretensioner consists of the SRSCM and two Seat Belt Pretensioners (BPT). The SRSCM sets above DTC(s) if it detects short to ground on the BPT circuit.

DTC DETECTING CONDITION E7DB074E

DTC	Condition	Probable cause
B1363 B1369	<ul style="list-style-type: none"> • Short to ground between BPT and SRSCM • Seat Belt Pretensioner (BPT) Malfunction • SRSCM Malfunction 	<ul style="list-style-type: none"> • Short to ground circuit on wiring harness • Seat Belt Pretensioner (BPT) squib • SRSCM

SCHEMATIC DIAGRAM E0B0CB0A



SBLRT6250L

TERMINAL & CONNECTOR INSPECTION E61C7A42

Refer to the DESCRIPTION in this TROUBLESHOOTING section.


INSPECTION PROCEDURE ED1E80E8

1. PREPARATION
Refer to the DESCRIPTION in this TROUBLESHOOTING section.

2. CHECK SHORT TO GROUND

- 1) Measure resistance between the terminal 1(2) of BPT harness connector and chassis ground.

Specification (resistance) : infinite



SBLRT6254L

- 2) Is the measured resistance within specification?

YES

Check the BPT Module.

NO

Repair or replace the wiring harness between the BPT and the SRSCM.

3. CHECK THE BPT MODULE

- 1) Replace the Belt Pretensioner (BPT) with a new one.
Refer to "Belt Pretensioner (BPT)" section in this SERVICE MANUAL.
- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.
- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC related to Belt Pretensioner (BPT)?

YES

Go to next step.

NO

Replace BPT module.

4. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE E79D17F8


1. PREPARATION

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

2. CHECK SHORT TO BATTERY LINE

- 1) Connect the battery negative cable to the battery.
- 2) Turn the ignition switch to ON.
- 3) Measure voltage between the terminal 1(2) of BPT harness connector and chassis ground.

Specification (voltage) : Approximately 0 V



SBLRT6255L

- 4) Is the measured voltage within specification?

YES

Check the BPT Module.

NO

Repair the short to battery line circuit on wiring harness between the BPT and the SRSCM.

3. CHECK THE BPT MODULE

- 1) Replace the Belt Pretensioner (BPT) with a new one.
Refer to "Belt Pretensioner (BPT)" section in this SERVICE MANUAL.
- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.

- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC related to Belt Pretensioner (BPT)?

YES

Go to next step.

NO

Replace BPT module.

4. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN
Refer to the DESCRIPTION in this TROUBLESHOOTING section.

DTC B1395 FIRING LOOPS INTERCONNECTION FAULT

DTC DESCRIPTION E027D453

While start up phase, SRSCM will measure cross link of squibs. If one of them is failed during interconnection test, then SRSCM will store interconnection fault. Once the interconnection fault is detected, it remains active continuously till the fault is erased. Only one fault code is assigned for all interconnection fault.

TERMINAL & CONNECTOR INSPECTION EECD3199

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE E0656F8A

1. PREPARATION
Refer to the DESCRIPTION in this TROUBLESHOOTING section.
2. CHECK SHORT CIRCUIT
 - 1) Measure resistance between following squibs.
(DAB - PAB, , DAB - CAB, DAB - BPT, PAB - CAB, PAB - BPT, CAB - BPT)

Specification (resistance) : infinite

- 2) Is the measured resistance within specification?

YES

Go to next step.

NO

Repair or replace the wiring harness between two squibs.

3. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN
Refer to the DESCRIPTION in this TROUBLESHOOTING section.

DTC B1400	SIDE IMPACT SENSOR [FRONT-DRIVER] DEFECT
DTC B1403	SIDE IMPACT SENSOR [FRONT-PASSENGER] DEFECT
DTC B1409	SIDE IMPACT SENSOR [FRONT-DRIVER] COMMUNICATION ERROR
DTC B1410	SIDE IMPACT SENSOR [FRONT-PASSENGER] COMMUNICATION ERROR


DTC DESCRIPTION E7C1CA1D

The detecting system for side crash consists of the SRSCM and four Side Impact Sensors (SIS). The SRSCM sets above DTC(s) if it detects that any SIS is defective or there is communication error between any SIS and the SRSCM.

DTC DETECTING CONDITION EFA2D8F7

DTC	Condition	Probable cause
B1400 B1403 B1409 B1410	<ul style="list-style-type: none"> • Open between SIS and SRSCM • Side Impact Sensor (SIS) Malfunction • SRSCM Malfunction 	<ul style="list-style-type: none"> • Wiring Harness • Side Impact Sensor (SIS) • SRSCM

SCHEMATIC DIAGRAM EB8523E1



SBLRT6260L

TERMINAL & CONNECTOR INSPECTION E276ABDE

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE EE9E71F6


1. PREPARATION

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

2. CHECK SIS CIRCUIT

- 1) Measure resistance between the terminal 1 of SIS harness connector and the terminal 70(69) of SRSCM harness connector.
- 2) Measure resistance between the terminal 2 of SIS harness connector and the terminal 71(68) of SRSCM harness connector.

Specification (resistance) : below 1



SBLRT6261L

- 3) Is the measured resistance within specification?

YES

Check Side Impact Sensor.

NO

Repair or replace the wiring harness between the SIS and the SRSCM.

3. CHECK THE SIDE IMPACT SENSOR

- 1) Replace the Side Impact Sensor(SIS) with a new one.
Refer to "Side Impact Sensor(SIS)" section in this SERVICE MANUAL.
- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.

- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC related to Side Impact Sensor(SIS)?

YES

Go to next step.

NO

Replace SIS.

4. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN
Refer to the DESCRIPTION in this TROUBLESHOOTING section.

DTC B1401 SIDE IMPACT SENSOR [FRONT-DRIVER] CIRCUIT SHORT TO GROUND
DTC B1404 SIDE IMPACT SENSOR [FRONT-PASSENGER] CIRCUIT SHORT TO GROUND


DTC DESCRIPTION E97ECDA8

The detecting system for side crash consists of the SRSCM and four Side Impact Sensors (SIS). The SRSCM sets above DTC(s) if it detects short to ground on the SIS circuit.

DTC DETECTING CONDITION E0FA7544

DTC	Condition	Probable cause
B1401 B1404	<ul style="list-style-type: none"> • Short to ground between SIS and SRSCM • Side Impact Sensor (SIS) Malfunction • SRSCM Malfunction 	<ul style="list-style-type: none"> • Short to ground circuit on wiring harness • Side Impact Sensor (SIS) • SRSCM

SCHEMATIC DIAGRAM EE98102E



SBLRT6260L

TERMINAL & CONNECTOR INSPECTION EF53CDBA

Refer to the DESCRIPTION in this TROUBLESHOOTING section.


INSPECTION PROCEDURE E384A624

1. PREPARATION
Refer to the DESCRIPTION in this TROUBLESHOOTING section.

2. CHECK SHORT TO GROUND

- 1) Measure resistance between the terminal 1 of SIS harness connector and chassis ground.

Specification (resistance) : infinite



SBLRT6262L

- 2) Is the measured resistance within specification?

YES

Check the SIS.

NO

Repair or replace the wiring harness between the SIS and the SRSCM.

3. CHECK THE SIDE IMPACT SENSOR

- 1) Replace the Side Impact Sensor(SIS) with a new one.
Refer to "Side Impact Sensor(SIS)" section in this SERVICE MANUAL.
- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.
- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC related to Side Impact Sensor(SIS)?

YES

Go to next step.

NO


Replace SIS module.

4. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

- 1) Connect the battery negative cable to the battery.
- 2) Turn the ignition switch to ON.
- 3) Measure voltage between the terminal 1 of SIS harness connector and chassis ground.

Specification(voltage) : Approximately 0V



SBLRT6263L

- 4) Is the measured voltage within specification?

YES

Check the SIS Module.

NO

Repair the short to battery line circuit on wiring harness between the SIS and the SRSCM.

3. CHECK THE SIS MODULE

- 1) Replace the Side Impact Sensor(SIS) with a new one.
Refer to "Side Impact Sensor(SIS)" section in this SERVICE MANUAL.
- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.
- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC related to Side Impact Sensor(SIS)?

YES

Go to next step.

NO

Replace SIS module.

4. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN
Refer to the DESCRIPTION in this TROUBLESHOOTING section.

DTC B1414 SIDE IMPACT SENSOR [FRONT-DRIVER] WRONG ID
DTC B1415 SIDE IMPACT SENSOR [FRONT-PASSENGER] WRONG ID

DTC DESCRIPTION E7BCC6BD

The detecting system for side crash consists of the SRSCM and four Side Impact Sensors (SIS). The SRSCM sets above DTC(s) if it detects that wrong SIS is used.

DTC DETECTING CONDITION E2A0FF8A

DTC	Condition	Probable cause
B1414 B1415	<ul style="list-style-type: none">• Wrong Side Impact Sensor (SIS)• SRSCM Malfunction	<ul style="list-style-type: none">• Side Impact Sensor (SIS)• SRSCM

TERMINAL & CONNECTOR INSPECTION E394EEA7

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE E04EC6EF

If above DTC is detected replace the side impact sensor.

TERMINAL & CONNECTOR INSPECTION E67565A8

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE E0265A0E


1. PREPARATION
Refer to the DESCRIPTION in this TROUBLESHOOTING section.
2. CHECK CAB RESISTANCE

 **CAUTION**

Never attempt to measure the circuit resistance of the airbag module(squib) even if you are using the specified tester.

- 1) Connect the Dummy and the Dummy Adapter on CAB harness connector.
Refer to "SPECIAL SERVICE TOOL" section in this SERVICE MANUAL for the SST No. of Dummy and Dummy Adapter.
- 2) Measure resistance between the terminal 38(39) and 37(40) of SRSCM harness connector.

Specification (resistance) : 1.8 ~ 4.8



SBLRT6271L

- 3) Is the measured resistance within specification?

YES

Replace the Curtain Airbag(CAB) module.

NO


Check open circuit.

TROUBLESHOOTING

3. CHECK OPEN CIRCUIT

- 1) Measure resistance between the terminal 1(2) of CAB harness connector and the terminal 38(39) of SRSCM harness connector.
- 2) Measure resistance between the terminal 2(1) of CAB harness connector and the terminal 37(40) of SRSCM harness connector.

Specification (resistance) : below 1



SBLRT6272L

- 3) Is the measured resistance within specification?

YES

Check short circuit.


NO

Repair or replace the wiring harness between the CAB and the SRSCM.

4. CHECK SHORT CIRCUIT

- 1) Measure resistance between the terminal 1(2) and 2(1) of CAB harness connector.

Specification (resistance) : infinite



SBLRT6273L

- 2) Is the measured resistance within specification?

YES

Go to next step.

NO


Repair or replace the wiring harness between the CAB and the SRSCM.

5. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN
Refer to the DESCRIPTION in this TROUBLESHOOTING section.

2. CHECK SHORT TO GROUND

- 1) Measure resistance between the terminal 1(2) of CAB harness connector and chassis ground.

Specification (resistance) : infinite



SBLRT6274L

- 2) Is the measured resistance within specification?

YES

Check the CAB Module..

NO

Repair or replace the wiring harness between the CAB and the SRSCM.

3. CHECK THE CAB MODULE

- 1) Replace the Curtain Airbag(CAB) with a new one.
Refer to "Curtain Airbag(CAB)" section in this SERVICE MANUAL.
- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.
- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC related to Curtain Airbag(CAB)?

YES

Go to next step.

NO

Replace CAB module.

4. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE E8312668


1. PREPARATION

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

2. CHECK SHORT TO BATTERY LINE

- 1) Connect the battery negative cable to the battery.
- 2) Turn the ignition switch to ON.
- 3) Measure voltage between the terminal 1(2) of CAB harness connector and chassis ground.

Specification (voltage) : Approximately 0 V



SBLRT6275L

- 4) Is the measured voltage within specification?

YES

Check the CAB Module.

NO

Repair the short to battery line circuit on wiring harness between the CAB and the SRSCM.

3. CHECK THE CAB MODULE

- 1) Replace the Curtain Airbag(CAB) with a new one.
Refer to "Curtain Airbag(CAB)" section in this SERVICE MANUAL.
- 2) Install the DAB module and connect the DAB connector.
- 3) Connect the connectors of the PAB, CAB, BPT, FIS and SIS.
- 4) Connect the SRSCM connector.
- 5) Connect the battery negative cable to the battery.
- 6) Connect a Hi-Scan(Pro) to the data link connector.

- 7) Turn the ignition switch to ON and check the vehicle again.
Does Hi-Scan (Pro) indicate any DTC related to Curtain Airbag(CAB)?

YES

Go to next step.

NO

Replace CAB module.

4. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN
Refer to the DESCRIPTION in this TROUBLESHOOTING section.

TERMINAL & CONNECTOR INSPECTION EBF7AADF

Refer to the DESCRIPTION in this TROUBLESHOOTING part.

INSPECTION PROCEDURE E9B16395


1. PREPARATION

Refer to the DESCRIPTION in this TROUBLESHOOTING part.

2. CHECK OPEN CIRCUIT

- 1) Disconnect the connector of the PAD switch.
- 2) Measure resistance between the terminal 60 of the SRSCM harness connector and 1 of PAD switch connector.

Specification (resistance) : below 1



SBLRT6281L

3) Is the measured resistance within specification?

YES

Check short to battery line.

NO


Replace the harness between the SRSCM and the PAD switch.

3. CHECK SHORT TO BATTERY LINE

- 1) Connect the battery negative cable to the battery.
- 2) Turn the ignition switch to ON.
- 3) Turn the ignition switch to LOCK, and wait for 30 seconds.

- 4) Measure voltage between the terminal 1 of PAD switch harness connector and chassis ground.

Specification (voltage) : Approximately 0 V



SBLRT6282L

- 5) Is the measured voltage within specification?

YES

Go to next step.

NO

Repair or replace the wiring harness between the PAD switch and the SRSCM.


4. CHECK THE PAD SWITCH

- 1) Connect the SRSCM connector.
- 2) Connect the PAD switch.
- 3) Connect the battery negative cable to the battery.
- 4) Turn the ignition switch to ON.
- 5) Measure current between the terminal 60 of the SRSCM harness connector and 1 of PAD switch connector.

Specification (current) :

PAD switch (Enabled position) : 3.7 ~ 7.5 mA

PAD switch (Disabled position) : 10 ~ 17 mA



SBLRT6283L

6) Is the measured current within specification?

YES

Go to next step.

NO

Replace the PAD switch.

5. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN
Refer to the DESCRIPTION in this TROUBLESHOOTING part.

DTC B1528 PASSENGER AIRBAG DEACTIVATION SWITCH SHORT OR SHORT TO GROUND


DTC DESCRIPTION E45B275C

The deactivation system for the passenger airbag consists of the SRSCM and the Passenger Airbag Deactivation(PAD) switch. The above DTC is recored when PAD switch short or short to ground is detected in the PAD system circuit.

DTC DETECTING CONDITION E2A88B03

DTC	Condition	Probable cause
B1528	<ul style="list-style-type: none"> • Short to ground between PAD switch and SRSCM • PAD switch malfunction • SRSCM malfunction 	<ul style="list-style-type: none"> • PAD switch • Wiring harness • SRSCM

SCHEMATIC DIAGRAM E5831580



SBLRT6280L

SPECIFICATION E3048475

PAD Switch Status	Current (mA)	Related DTC
Open or Short to Battery	< 2.4	B1527
PAD Enabled Position	3.7 ~ 7.5	
PAD Disabled Position	10 ~ 17	
Short or Short to Ground	> 22	B1528

TERMINAL & CONNECTOR INSPECTION E5D631A2

Refer to the DESCRIPTION in this TROUBLESHOOTING part.

INSPECTION PROCEDURE

EC6B0301


1. PREPARATION

Refer to the DESCRIPTION in this TROUBLESHOOTING part.

2. CHECK SHORT TO GROUND

- 1) Disconnect the connector of the PAD switch.
- 2) Measure resistance between the terminal 1 of PAD switch connector and chassis ground.

Specification (resistance) : infinite



SBLRT6284L

3) Is the measured resistance within specification?

YES

Check short circuit.


NO

Replace the harness between the SRSCM and the PAD switch.

3. CHECK SHORT CIRCUIT

- 1) Measure resistance between 1 and 2 of PAD switch connector.
- 2) Measure resistance between 1 and 4 of PAD switch connector.

Specification (resistance) : infinite



SBLRT6285L

3) Is the measured resistance within specification?

YES

Go to next step.

NO

Repair or replace the wiring harness between the PAD switch and the SRSCM.


4. CHECK THE PAD SWITCH

- 1) Connect the SRSCM connector.
- 2) Connect the PAD switch.
- 3) Connect the battery negative cable to the battery.
- 4) Turn the ignition switch to ON.
- 5) Measure current between the terminal 60 of the SRSCM harness connector and 1 of PAD switch connector.

Specification (current) :

PAD switch (Enabled position) : 3.7 ~ 7.5 mA

PAD switch (Disabled position) : 10 ~ 17 mA



SBLRT6286L

6) Is the measured current within specification?

YES

Go to next step.

NO

Replace the PAD switch.

5. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN
Refer to the DESCRIPTION in this TROUBLESHOOTING part.

DTC B1529 PASSENGER AIRBAG DEACTIVATION SWITCH DEFECT
DTC B1530 PASSENGER AIRBAG DEACTIVATION SWITCH INSTABILITY


DTC DESCRIPTION E93F913D

The deactivation system for the passenger airbag consists of the SRSCM and the Passenger Airbag Deactivation(PAD) switch. The above DTC is recored when the defect or instability of PAD switch is detected in the PAD system circuit.

DTC DETECTING CONDITION E0DA1574

DTC	Condition	Probable cause
B1529 B1530	<ul style="list-style-type: none"> PAD switch malfunction SRSCM — Malfunction 	<ul style="list-style-type: none"> PAD switch Wiring harness SRSCM

SCHEMATIC DIAGRAM E2D3CB53



SBLRT6280L

SPECIFICATION E94FE925

PAD Switch Status	Current (mA)	Related DTC
Open or Short to Battery	< 2.4	B1527
PAD Enabled Position	3.7 ~ 7.5	
PAD Disabled Position	10 ~ 17	
Short or Short to Ground	> 22	B1528

TERMINAL & CONNECTOR INSPECTION E5D6C715

Refer to the DESCRIPTION in this TROUBLESHOOTING part.

INSPECTION PROCEDURE E1677313


1. PREPARATION

Refer to the DESCRIPTION in this TROUBLESHOOTING part.

2. CHECK POWER SUPPLY

- 1) Connect the battery negative cable to the battery.
- 2) Turn the ignition switch to ON.
- 3) Measure voltage between the terminal and 4 of PAD switch connector and chassis ground.

Specification (voltage) : 10.6 ~ 16.5 V



SBLRT6287L

- 4) Is the measured voltage within specification?

YES

Check ground circuit.


NO

Replace the harness between the battery line and the PAD switch.

3. CHECK GROUND CIRCUIT

- 1) Turn the ignition switch to OFF.
- 2) Disconnect the battery negative cable from the battery.
- 3) Disconnect the connector of the PAD switch.
- 4) Measure resistance between the terminal 2 of PAD switch connector and chassis ground.

Specification (resistance) : 0



SBLRT6288L

5) Is the measured resistance within specification?

YES

Go to next step.


NO

Repair or replace the wiring harness between the PAD switch and the chassis ground.

4. CHECK THE PAD SWITCH

- 1) Connect the SRSCM connector.
- 2) Connect the PAD switch.
- 3) Connect the battery negative cable to the battery.
- 4) Turn the ignition switch to ON.
- 5) Measure current between the terminal 60 of the SRSCM harness connector and 1 of PAD switch connector.

Specification (current) :
PAD switch (Enabled position) : 3.7 ~ 7.5 mA
PAD switch (Disabled position) : 10 ~ 17 mA



SBLRT6286L

6) Is the measured current within specification?

YES

Go to next step.

NO

Replace the PAD switch.

5. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN
Refer to the DESCRIPTION in this TROUBLESHOOTING part.

DTC B1620 SUPPLEMENTAL RESTRAINT SYSTEM CONTROL MODULE INTERNAL FAULT (REPLACE SRSCM)

DTC DESCRIPTION E2A27131

The Supplemental Restraint System Control Module (SRSCM) runs diagnostics to monitor the condition of its internal circuits and all external components in the restraint system. If a fault is detected in the electronic accelerometer or in the microprocessor, the SRSCM will inhibit deployment to minimize the risk of inadvertent deployments.

Once an internal fault is qualified, the internal fault is latched and warning lamp will be turned on. If an internal fault is qualified, the SRSCM must be replaced. The Hi-Scan tool can't clear an internal fault. All internal faults are DTC B1620.

DTC DETECTING CONDITION E29CDD22

DTC	Condition	Probable cause
B1620	<ul style="list-style-type: none">SRSCM internal fault : acceleration sensor, microcomputer power supply, watchdog etc	<ul style="list-style-type: none">SRSCM

INSPECTION PROCEDURE E5F53E4E

If the above mentioned DTC is confirmed it can't be cleared by Hi-Scan tool, the SRSCM should be replaced.

DTC B1650	CRASH RECORDED - FRONTAL (REPLACE SRSCM)
DTC B1651	CRASH RECORDED - DRIVER SIDE (REPLACE SRSCM)
DTC B1652	CRASH RECORDED - PASSENGER SIDE (REPLACE SRSCM)
DTC B1657	CRASH RECORDED - BELT PRETENSIONER ONLY
DTC B1658	BELT PRETENSIONER 6 TIMES DEPLOYMENT (REPLACE SRSCM)


DTC DESCRIPTION EDC1215F

When a deployment of any restraint system for seat belt pretensioner and frontal and side air bags occurs, the crash output is activated. The purpose of this output is to signal BCM (Body Control Module) in the vehicle to unlock the vehicle doors. If a crash output is in progress, a second crash output signal will not be sent unless the first one is completed. The SRSCM doesn't perform diagnostics on the crash output function. After a frontal or side crash event is sensed and algorithm makes firing decision, above mentioned crash record is stored after squib deployment.

DTC DETECTING CONDITION EBD32503

DTC	Condition	Probable cause
B1650 B1651 B1652 B1657 B1658	<ul style="list-style-type: none"> • Frontal crash • Side crash • Seat belt pretensioner only deployed 	<ul style="list-style-type: none"> • SRSCM • Front Impact Sensor • Side Impact Sensor • Seat Belt Pretensioner

SCHEMATIC DIAGRAM EC279D28



SBLRT6290L

INSPECTION PROCEDURE EEFE25D3

If the above mentioned DTC is confirmed it can't be cleared by Hi-Scan tool except for the B1657, and the SRSCM should be replaced. However, for the DTC B1657, Belt pretensioner only deployment, it can be erased for 5 times and the SRSCM can be reusable. If the deployment of Belt pretensioner reaches to 6 times, the SRSCM will set DTC B1658 and the SRSCM should be replaced accordingly.

DTC B2500 SRS WARNING LAMP FAILURE


DTC DESCRIPTION E94AAE61

The SRS warning lamp is located in the cluster. When the airbag system is normal, the SRS warning lamp turns on for approx. 6 seconds after the ignition switch is turned to ON, and then turns off automatically. If there is a malfunction in the airbag system, the SRS warning lamp lights up to inform the driver of the abnormality. The SRSCM shall measure the voltage at the SRS warning lamp output pin, both when the lamp is on and when the lamp is off, to detect whether the commanded state matches the actual state.

DTC DETECTING CONDITION EDEB4A4B

DTC	Condition	Probable cause
B2500	<ul style="list-style-type: none"> • Airbag fuse • Warning Lamp Bulb • Open between warning lamp and SRSCM • Short to ground or battery line between the warning lamp and SRSCM • SRSCM Malfunction 	<ul style="list-style-type: none"> • Fuse • Warning lamp bulb • Wiring Harness • SRSCM

SCHEMATIC DIAGRAM E40E535F



SBLRT6300L

TERMINAL & CONNECTOR INSPECTION E7B1FDA3

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE EDF952B4

1. PREPARATION

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

2. CHECK THE FUSE

- 1) Remove the airbag fuse and the airbag warning lamp fuse from junction box.
- 2) Inspect the fuses. Are the fuses normal?

YES

Check the warning lamp bulb.

NO

Repair or replace the fuses.

3. CHECK THE WARNING LAMP BULB

- 1) Remove the bulb from the instrument cluster.
- 2) Inspect the bulb. Is the bulb normal?

YES

Check source voltage.


NO

Repair or replace the bulb.

4. CHECK SOURCE VOLTAGE

- 1) Connect the battery negative cable to the battery.
- 2) Turn the ignition switch to ON.
- 3) Measure voltage between the terminal 13 of the Instrument Cluster harness connector and chassis ground.

Specification (voltage) : 10.6 ~ 16.5 V



4) Is the measured voltage within specification?

YES

Check short to battery line.


NO

Repair or replace the wiring harness between ignition switch and the Warning Lamp.

5. CHECK SHORT TO BATTERY LINE

1) Measure voltage between the terminal 14 of the Instrument Cluster harness connector and chassis ground.

Specification (voltage) : Approximately 0 V



SBLRT6302L

2) Is the measured voltage within specification?

YES

Check short or short to ground.

NO

Repair the short to battery line circuit on wiring harness between the SRSCM and the Warning Lamp.

6. CHECK SHORT OR SHORT TO GROUND


1) Turn the ignition switch to LOCK.

2) Disconnect the battery negative cable from the battery.

3) Measure resistance between the terminal 14 of the Instrument Cluster harness connector and chassis ground.

4) Measure resistance between the terminal 13 and 14 of the Instrument Cluster harness connector.

Specification (resistance) : infinite



SBLRT6303L

5) Is the measured resistance within specification?

YES

Check open circuit.


NO

Repair the short or short to ground circuit on wiring harness between the SRSCM and the Warning Lamp.

7. CHECK OPEN CIRCUIT

1) Measure resistance between the terminal 14 of the Instrument Cluster connector and the terminal 27 of SRSCM harness connector.

Specification (resistance) : below 1



SBLRT6304L

2) Is the measured resistance within specification?

YES

Go to next step.

NO

Repair the open circuit on wiring harness between the SRSCM and the Warning Lamp.

8. CLEAR THE DTC AND CHECK THE VEHICLE AGAIN
Refer to the DESCRIPTION in this TROUBLESHOOTING section.

TERMINAL & CONNECTOR INSPECTION E11FDFA8

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

INSPECTION PROCEDURE E83DF308

1. PREPARATION

Refer to the DESCRIPTION in this TROUBLESHOOTING section.

2. CHECK THE FUSE

- 1) Remove the airbag fuse and the PAD lamp fuse from junction box.
- 2) Inspect the fuses. Are the fuses normal?

YES

Check the PAD lamp bulb.

NO

Repair or replace the fuses.

3. CHECK THE PAD LAMP BULB

- 1) Remove the bulb from the instrument cluster.
- 2) Inspect the bulb. Is the bulb normal?

YES

Check source voltage.


NO

Repair or replace the bulb.

4. CHECK SOURCE VOLTAGE

- 1) Connect the battery negative cable to the battery.
- 2) Turn the ignition switch to ON.
- 3) Measure voltage between the terminal 1 of the Instrument Cluster harness connector and chassis ground.

Specification (voltage) : 10.6 ~ 16.5 V



SBLRT6311L

4) Is the measured voltage within specification?

YES

Check short to battery line.


NO

Repair or replace the wiring harness between ignition switch and the PAD Lamp.

5. CHECK SHORT TO BATTERY LINE

1) Measure voltage between the terminal 2 of the Instrument Cluster harness connector and chassis ground.

Specification (voltage) : Approximately 0 V



SBLRT6312L

2) Is the measured voltage within specification?

YES

Check short or short to ground.


NO

Repair the short to battery line circuit on wiring harness between the SRSCM and the PAD Lamp.

6. CHECK SHORT OR SHORT TO GROUND

- 1) Turn the ignition switch to LOCK.
- 2) Disconnect the battery negative cable from the battery.
- 3) Measure resistance between the terminal 2 of the Instrument Cluster harness connector and chassis ground.
- 4) Measure resistance between the terminal 1 and 2 of the Instrument Cluster harness connector.

Specification (resistance) : infinite



SBLRT6313L

- 5) Is the measured resistance within specification?

YES

Check open circuit.


NO

Repair the short or short to ground circuit on wiring harness between the SRSCM and the PAD Lamp.

7. CHECK OPEN CIRCUIT

- 1) Measure resistance between the terminal 2 of the Instrument Cluster connector and the terminal 56 of SRSCM harness connector.

Specification (resistance) : below 1



SBLRT6314L

2) Is the measured resistance within specification?

YES

Go to next step.

NO

Repair the open circuit on wiring harness between the SRSCM and the PAD Lamp.

8. **CLEAR THE DTC AND CHECK THE VEHICLE AGAIN**
Refer to the DESCRIPTION in this TROUBLESHOOTING section.

AIR BAG MODULE DISPOSAL

AIRBAG DISPOSAL E50F62AD

SPECIAL TOOL REQUIRED

Deployment tool 0957A-34100A

Before scrapping any airbags or side airbags (including those in a whole vehicle to be scrapped), the airbags or side airbags must be deployed. If the vehicle is still within the warranty period, before deploying the airbags or side airbags, the Technical Manager must give approval and/or special instruction. Only after the airbags or side airbags have been deployed (as the result of vehicle collision, for example), can they be scrapped.

If the airbags or side airbags appear intact (not deployed), treat them with extreme caution. Follow this procedure.

DEPLOYING AIRBAGS IN THE VEHICLE

If an SRS equipped vehicle is to be entirely scrapped, its airbags or side airbags should be deployed while still in the vehicle. The airbags or side airbags should not be considered as salvageable parts and should never be installed in another vehicle.

1. Turn the ignition switch OFF, and disconnect the battery negative cable and wait at least three minutes.
2. Confirm that each airbag or side airbag is securely mounted.
3. Confirm that the special tool is functioning properly by following the check procedure.

DRIVER'S AIRBAG :

1. Remove the driver's airbag and install the SST(0957A-38500).
2. Install the driver's airbag on the steering wheel.

FRONT PASSENGER'S AIRBAG :

1. Remove the glove box, then disconnect the 2P connector between the front passenger's airbag and SRS main harness.
2. Install the SST(0957A-3E110).

CURTAIN AIRBAG :

1. Disconnect the 2P connector between the curtain airbag and wire harness.
2. Install the SST(0957A-38500).

SEAT BELT PRETENSIONER :

1. Disconnect the 2P connector from the seat belt pretensioner.
2. Install the SST(0957A-38500).
3. Place the deployment tool at least thirty feet (10 meters) away from the airbag.
4. Connect a 12 volt battery to the tool.
5. Push the tool's deployment switch. The airbag should deploy (deployment is both highly audible and visible: a loud noise and rapid inflation of the bag, followed by slow deflection)
6. Dispose of the complete airbag. No part of it can be reused. Place it in a sturdy plastic bag and seal it securely.



ERKD002U

DEPLOYING THE AIRBAG OUT OF THE VEHICLE

If an intact airbag has been removed from a scrapped vehicle, or has been found defective or damaged during transit, storage or service, it should be deployed as follows :

1. Confirm that the special tool is functioning properly by following the check procedure.
2. Position the airbag face up, outdoors on flat ground at least thirty feet (10meters) from any obstacles or people.

DISPOSAL OF DAMAGED AIRBAG

1. If installed in a vehicle, follow the removal procedure of driver's airbag front passenger's and side airbag.
2. In all cases, make a short circuit by twisting together the two airbag inflator wires.
3. Package the airbag in exactly the same packing that the new replacement part come in.