


CLUTCH

SECTION CL

CONTENTS

PRECAUTIONS	2	CLUTCH DAMPER	14
Precautions	2	Components	14
PREPARATION	3	Inspection	14
Special Service Tools	3	PIPING	15
Commercial Service Tools	3	Removal	15
NOISE, VIBRATION AND HARSHNESS (NVH)		Installation	15
TROUBLESHOOTING	4	CLUTCH RELEASE MECHANISM	16
NVH Troubleshooting Chart	4	Components	16
CLUTCH	4	Removal	16
CLUTCH SYSTEM	5	Inspection	16
Components	5	Installation	16
Inspection and Adjustment	6	CLUTCH DISC, CLUTCH COVER AND	
ADJUSTING CLUTCH PEDAL	6	FLYWHEEL	18
AIR BLEEDING PROCEDURE	6	Components	18
CLUTCH MASTER CYLINDER	9	Inspection and Adjustment	18
Components	9	CLUTCH DISC	18
Removal	10	CLUTCH COVER	19
Installation	10	FLYWHEEL	19
Disassembly	10	Installation	19
Inspection	10	SERVICE DATA AND SPECIFICATIONS (SDS)	20
Assembly	11	Clutch Control System	20
OPERATING CYLINDER	12	Clutch Master Cylinder	20
Components	12	Clutch Operating Cylinder	20
Removal	12	Clutch Damper	20
Disassembly	12	Clutch Disc	20
Inspection	12	Clutch Cover	20
Assembly	13	Clutch Pedal	21
Installation	13		



Precautions

NFCL0001




- Recommended fluid is brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas.
- When removing and installing clutch piping, use Tool.
- Use new brake fluid to clean or wash all parts of master cylinder, operating cylinder and clutch damper.
- Never use mineral oils such as gasoline or kerosene. It will ruin the rubber parts of the hydraulic system.

WARNING:

After cleaning clutch disc, wipe it with a dust collector. Do not use compressed air.


Special Service Tools

NFCL0002

Tool number Tool name	Description	
ST20630000 Clutch aligning bar	 Installing clutch cover and clutch disc a: 15.8 mm (0.622 in) dia. b: 22.9 mm (0.902 in) dia. c: 45.0 mm (1.772 in)	GI MA EM
ST20050240 Diaphragm spring adjusting wrench	 Adjusting unevenness of diaphragm spring of clutch cover a: 150 mm (5.91 in) b: 25 mm (0.98 in)	LC EC FE
KV32101000 Pin punch	 Removing and installing spring pin for clutch master cylinder a: 4 mm (0.16 in) dia.	CL MT

Commercial Service Tools

NFCL0003

Tool name	Description	
1 Flare nut crowfoot 2 Torque wrench	 Removing and installing clutch piping a: 10 mm (0.39 in)	AT AX SU BR

ST
RS
BT
HA
SC
EL
IDX

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

NVH Troubleshooting Chart

NFCL0004S01

Use the chart below to help you find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

CLUTCH


NFCL0004S0101

Reference page																	
SUSPECTED PARTS (Possible cause)		CL-6	CL-6	CL-9	CL-12	Refer to EM-58, "Removal and Installation".										CL-16	CL-18
CLUTCH PEDAL (Free play out of adjustment)																CL-18	CL-18
CLUTCH LINE (Air in line)																CL-18	CL-18
MASTER CYLINDER PISTON CUP (Damaged)																CL-18	CL-18
OPERATING CYLINDER PISTON CUP (Damaged)																CL-18	CL-18
ENGINE MOUNTING (Loose)																CL-18	CL-18
RELEASE BEARING (Worn, dirty or damaged)																CL-18	CL-18
CLUTCH DISC (Out of true)																CL-18	CL-18
CLUTCH DISC (Runout is excessive)																CL-18	CL-18
CLUTCH DISC (Lining broken)																CL-18	CL-18
CLUTCH DISC (Dirty or burned)																CL-18	CL-18
CLUTCH DISC (Oily)																CL-18	CL-18
CLUTCH DISC (Worn out)																CL-18	CL-18
CLUTCH DISC (Hardened)																CL-18	CL-18
CLUTCH DISC (Lack of spline grease)																CL-18	CL-18
DIAPHRAGM SPRING (Damaged)																CL-19	CL-19
DIAPHRAGM SPRING (Out of tip alignment)																CL-19	CL-19
PRESSURE PLATE (Distortion)																CL-19	CL-19
FLYWHEEL (Distortion)																CL-19	CL-19
Symptom	Clutch grabs/chatters					1			2				2	2	2		
	Clutch pedal spongy		1	2	2												
	Clutch noisy						1										
	Clutch slips	1											2	2		3	4
	Clutch does not disengage	1	2	3	4			5	5	5	5	5			5	6	7

Components


NFCL0005

SEC. 300•305•306•465




SCL832


- | | | |
|---------------------------|---------------------|-----------------------------|
| 1. Pedal bracket | 9. Withdrawal lever | 16. ASCD clutch switch |
| 2. Clutch master cylinder | 10. Release bearing | 17. Washer |
| 3. Pedal stopper bolt | 11. Clutch hose | 18. Clutch hose connector |
| 4. Fulcrum pin | 12. Clutch cover | 19. Bushing |
| 5. Pin | 13. Clutch disc | 20. Stopper rubber |
| 6. Clutch pedal | 14. Clevis pin | 21. Clutch damper |
| 7. Operating cylinder | 15. Assist spring | 22. Clutch piping connector |
| 8. Air bleeder valve | | |



SCL715-A



SCL702



SCL833

Inspection and Adjustment

ADJUSTING CLUTCH PEDAL

Pedal Height

1. Adjust pedal height with ASCD clutch switch or pedal stopper bolt.

Pedal height "H":

LHD model:

179.5 - 189.5 mm (7.07 - 7.46 in)

RHD model:

193.5 - 203.5 mm (7.62 - 8.01 in)

2. Adjust pedal free play with master cylinder push rod. Then tighten lock nut.

Pedal free play "A":

9 - 16 mm (0.35 - 0.63 in)

- Push or step on clutch pedal until resistance is felt, and check the distance the pedal moves.

AIR BLEEDING PROCEDURE

VQ20DE (LHD) Model

1. Bleed air from clutch damper according to the following procedure.

- Carefully monitor fluid level at master cylinder during air bleeding operation.
 - Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- a. Top up reservoir of master cylinder with recommended brake fluid.
 - b. Connect a transparent vinyl tube to air bleeder valve.
 - c. Slowly depress clutch pedal to its full stroke and release it completely. Repeat this operation several times at 2 to 3 second intervals.
 - d. Holding clutch pedal depressed, open air bleeder valve to release air.
 - e. Close air bleeder valve.
 - f. Release clutch pedal and wait at least 5 seconds.
 - g. Repeat steps c through f above until brake fluid flows from air bleeder valve without air bubbles.

2. Bleed air from clutch operating cylinder according to the above same procedure.
3. Repeat the above air bleeding procedures 1 and 2 several times.

Tightening torque of air bleeder valve:

Refer to "Components", CL-5.

VQ20DE (RHD) Model

1. Bleed air from operating cylinder according to the following procedure.
NFCL0006S0202
 - **Carefully monitor fluid level at master cylinder during air bleeding operation.**
 - **Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.**
- a. Top up reservoir of master cylinder with recommended brake fluid.
- b. Connect a transparent vinyl tube to air bleeder valve.
- c. Slowly depress clutch pedal to its full stroke and release it completely. Repeat this operation several times at 2 to 3 second intervals.
- d. Holding clutch pedal depressed, open air bleeder valve to release air.
- e. Close air bleeder valve.
- f. Release clutch pedal and wait at least 5 seconds.
- g. Repeat steps c through f above until brake fluid flows from air bleeder valve without air bubbles.
2. Repeat the above air bleeding procedure several times.

Tightening torque of air bleeder valve:

Refer to "Components", CL-5.

VQ30DE Model

1. Bleed air from clutch piping connector according to the following procedure.
NFCL0006S0203
 - **Carefully monitor fluid level at master cylinder during air bleeding operation.**
 - **Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.**
- a. Top up reservoir of master cylinder with recommended brake fluid.
- b. Connect a transparent vinyl tube to air bleeder valve.
- c. Slowly depress clutch pedal to its full stroke and release it completely. Repeat this operation several times at 2 to 3 second intervals.
- d. Holding clutch pedal depressed, open air bleeder valve to release air.
- e. Close air bleeder valve.
- f. Release clutch pedal and wait at least 5 seconds.
- g. Repeat steps c through f above until brake fluid flows from air bleeder valve without air bubbles.
2. Bleed air from clutch operating cylinder according to the above same procedure.
3. Repeat the above air bleeding procedures 1 and 2 several times.

Tightening torque of air bleeder valve:


Refer to "Components", CL-5.

Components

NFCL0007

SEC. 305


VQ20DE (LHD) & VQ30DE models



SCL817-B

SEC. 305

VQ20DE (RHD) model



SCL743-C

Removal

NFCL0008

1. Drain brake fluid.

CAUTION:

Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.

2. Remove clutch tube using a flare nut wrench.
3. Remove snap pin between clutch pedal and push rod, and remove clevis pin.
4. Unscrew master cylinder assembly mounting nuts and remove master cylinder assembly from vehicle.


Installation

NFCL0009

1. Connect clutch tube to master cylinder assembly, and hand-tighten flare nut.
2. Install master cylinder assembly to vehicle, and tighten mounting nuts to the specified torque.

 : 8 - 11 N·m (0.8 - 1.1 kg-m, 69 - 95 in-lb)

3. Tighten clutch tube flare nut using a flare nut torque wrench.
-  : 15 - 18 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)
4. After installing clevis pin, install snap pin to connect clutch pedal to push rod.
5. After finishing the operation, bleed air from clutch piping connector and operating cylinder. (Refer to "Air Bleeding Procedure", CL-6.)



Disassembly

NFCL0010

1. Loosen push rod lock nut A to remove clevis and lock nut A.
2. Remove dust cover.
3. Remove stopper ring and stopper, and remove push rod from cylinder body. During removal, keep push rod depressed, to prevent piston inside master cylinder from popping out.
4. Remove piston assembly from cylinder body.

Inspection

NFCL0011

Check the following items, and replace if necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust or damage
- Piston with piston cup, for wear or damage
- Return spring, for wear or damage
- Dust cover, for cracks, deformation or damage
- Reservoir, for deformation or damage

Assembly

1. Apply rubber lubricant to the sliding part of piston assembly, and insert piston assembly. GI
2. After installing stopper to push rod, install stopper ring while keeping piston assembly depressed by hand, so that piston assembly will not pop out. MA

CAUTION:

Stopper ring cannot be reused. Always use a new stopper ring for assembly. EM

3. Install dust cover. LC
4. Install clevis to push rod, and tighten lock nut A to the specified torque. EC

 : 8 - 11 N·m (0.8 - 1.2 kg-m, 70 - 104 in-lb) FE

5. Install spring pin using a pin punch. CL

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

Components

NFCL0019

SEC. 306



SCL813

Removal

NFCL0020

1. Drain brake fluid.

CAUTION:

Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.

2. Remove union bolt and clutch hose from operating cylinder.
3. Remove operating cylinder mounting bolts, and remove cylinder from vehicle.

Disassembly

NFCL0021

Remove dust cover, and remove piston assembly from cylinder body.

Inspection

NFCL0022

Inspect for following, and replace parts if necessary.

- Damage, foreign material, wear, rust, and pinholes on the cylinder inner surface, piston, and sliding part of piston cup
- Weak spring
- Crack and deformation of dust cover

Assembly

1. Apply recommended rubber grease to piston cup and piston, and insert piston assembly. ^{NFCL0023}
2. Install dust cover.

GI

MA

EM

LC

Installation

Install the components in the reverse order of removal. Adhere to the operations described below. ^{NFCL0024}

EC

CAUTION:

Install the hose without twisting it.

FE

- The copper washer of the union bolt should not be reused. Always use a new copper washer for installation.
- After finishing the operation, bleed air from the clutch piping connector and operating cylinder. Refer to "Air Bleeding Procedure", CL-6.

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

Components

NFCL0041




Inspection

NFCL0042

Check the following items, and replace if necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust or damage
- Piston with piston cup, for wear or damage
- Damper rubber and plate for cracks, deformation or damage
- Piston spring, for wear or damage



Removal


NFCL0025

1. Remove fuel filter mounting bracket.
2. Remove air cleaner and air duct. Refer to EM-58, "REMOVAL AND INSTALLATION".
3. Drain brake fluid.

CAUTION:

Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.

4. Remove flare nut using a flare nut wrench.
5. Remove clutch hose and clutch tube.



Installation

NFCL0026

1. When installing clutch hose to bracket, face lock plate in the correct direction as shown to secure clutch hose.

CAUTION:

Install clutch hose without twisting or bending it.

2. Tighten flare nut to the specified torque, using a flare nut wrench.

: 15 - 18 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)

CAUTION:

Be careful not to damage flare nut and clutch tube.

3. Install clutch hose to operating cylinder, and tighten mounting bolts to the specified torque.


: 17 - 20 N·m (1.7 - 2.1 kg-m, 13 - 14 ft-lb)

4. After finishing the operation, bleed air from the clutch piping connector and operating cylinder. Refer to "Air Bleeding Procedure", CL-6.

Components

NFCL0027

SEC. 321




SCL814

Removal

NFCL0028

1. Remove manual transaxle from vehicle. Refer to MT-9, "Removal".
2. Move withdrawal lever enough to remove release bearing, and remove release bearing from clutch withdrawal lever.
3. Remove dust cover.
4. Remove retainer spring from withdrawal lever.



SCL733

Inspection

NFCL0029

- Replace the release bearing if it is seized, damaged, faulty in rotation direction, or has poor aligning function.
- Replace the withdrawal lever if its contact surface is worn abnormally.
- Replace the dust cover if it is deformed or cracked.

Installation


NFCL0030

1. Apply a coat of grease to parts as instructed in the following cautions and notes before installation.

CAUTION:

- Be sure to apply grease to the clutch components. Otherwise, abnormal noise, poor clutch disengagement, or clutch damage may occur. Wipe the excess grease off completely, because it may cause the clutch components to slip and shudder.
- Keep the clutch disc facing, pressure plate, and flywheel free of oil and grease.

- Clean old grease and abrasive materials off the grease application area.



NOTE:

- Equally apply a coat [approximately 1 mm (0.04 in) thick] of clutch sleeve grease to withdrawal lever and holder spring frictional surfaces.
 - Apply a coat of clutch sleeve grease to the grooves on contact surfaces of the withdrawal lever ball pin and inner surface of release bearing so that grease application, make sure that grease is flush with grooves.
 - Equally apply a thin coat of clutch sleeve grease to release bearing frictional surface. After grease application, install release bearing. Wipe off excess grease forced out during bearing installation. Remove release bearing.
2. Installation is in the reverse order of removal.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA



SC

EL

IDX

Components

NFCL0031




Inspection and Adjustment

CLUTCH DISC


NFCL0032

NFCL0032S01

- Check clutch disc for wear of facing.
Wear limit of facing surface to rivet head:
0.3 mm (0.012 in)



- Check clutch disc for backlash of spline and runout of facing.
Maximum spline backlash (at outer edge of disc):
Model 225 0.9 mm (0.035 in)
Model 240 1.0 mm (0.039 in)
Runout limit:
1.0 mm (0.039 in)
Distance of runout check point (from hub center):
Model 225 107.5 mm (4.232 in)
Model 240 115 mm (4.528 in)
- Check clutch disc for burns, discoloration or oil or grease leakage. Replace if necessary.



CLUTCH COVER


NFCL0032S02

- Check clutch cover installed on vehicle for unevenness of diaphragm spring toe height.

Uneven limit:

0.7 mm (0.028 in)

- If out of limit, adjust the height with Tool.



FLYWHEEL


NFCL0032S03

- Check contact surface of flywheel for slight burns or discoloration. Repair flywheel with emery paper.

- Check flywheel runout.

Maximum allowable runout:

Refer to EM-70, "Flywheel/drive plate runout".



Installation

NFCL0033

- Insert Tool into clutch disc hub when installing clutch cover and disc.

- Be careful not to allow grease to contaminate clutch facing.**

- Tighten bolts in numerical order.

First step:

⌚ : 10 - 20 N·m (1 - 2 kg-m, 7 - 14 ft-lb)

Final step:

Model 225

⌚ : 22 - 29 N·m (2.2 - 3.0 kg-m, 16 - 21 ft-lb)

Model 240

⌚ : 35 - 44 N·m (3.5 - 4.5 kg-m, 26 - 32 ft-lb)

Clutch Control System

NFCL0034

Type of clutch control	Hydraulic
------------------------	-----------

Clutch Master Cylinder

NFCL0035

Unit: mm (in)

Inner diameter	15.87 (5/8)
----------------	-------------

Clutch Operating Cylinder

NFCL0036

Unit: mm (in)

Inner diameter	VQ20DE model	17.46 (11/16)
	VQ30DE model	19.05 (3/4)

Clutch Damper

NFCL0043

Unit: mm (in)

Inner diameter	VQ20DE (LHD) model	19.05 (3/4)
----------------	--------------------	-------------

Clutch Disc

NFCL0038

Model	225
Facing size (Outer dia. × inner dia. × thickness)	225 mm × 150 mm × 3.5 mm (8.86 in × 5.91 in × 0.138 in)
Thickness of disc assembly With load	8.0 - 8.2 mm (0.315 - 0.323 in) with 4,903 N (500 kg, 1,102 lb)
Wear limit of facing surface to rivet head	0.3 mm (0.012 in)
Facing runout limit	1.0 mm (0.039 in)
Distance of runout check point (from the hub center)	107.5 mm (4.23 in)
Maximum spline backlash (at outer edge of disc)	0.9 mm (0.035 in)

Model	240
Facing size (Outer dia. × inner dia. × thickness)	240 mm × 160 mm × 3.5 mm (9.45 in × 6.30 in × 0.138 in)
Thickness of disc assembly With load	7.9 - 8.3 mm (0.311 - 0.327 in) with 5,688 N (580 kg, 1,279 lb)
Wear limit of facing surface to rivet head	0.3 mm (0.012 in)
Facing runout limit	1.0 mm (0.039 in)
Distance of runout check point (from the hub center)	115 mm (4.53 in)
Maximum spline backlash (at outer edge of disc)	1.0 mm (0.039 in)

Clutch Cover

NFCL0039

Model	225
Set load	5,394 N (550 kg, 1,213 lb)
Uneven limit of diaphragm spring toe height	0.7 mm (0.028 in)

Model	240
Set load	6,227 N (635 kg, 1,400 lb)
Uneven limit of diaphragm spring toe height	0.7 mm (0.028 in)

Clutch Pedal

Unit: mm (in)
NFCL0040

Model	LHD	RHD
Pedal height*	179.5 - 189.5 (7.07 - 7.46)	193.5 - 203.5 (7.62 - 8.01)
Pedal free play	9 - 16 (0.35 - 0.63)	

*: Measured from surface of dash reinforcement panel to surface of pedal pad.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

NOTES