

Suspension System

GENERAL	SS - 2
FRONT SUSPENSION SYSTEM	SS -25
REAR SUSPENSION SYSTEM	SS -41
TIRES AND WHEELS	SS -55

GENERAL

SPECIFICATIONS EE058C94

FRONT SUSPENSION SYSTEM

ITEM			SPECIFICATION	
Type			Macpherson strut	
Shock absorber	Type	Double-acting, Gas filled		
	Stroke mm	163.8		
	Expansion mm	502.1 ± 3		
	Compression mm	338.3 ± 3		
	Damping force (0.3 m/s)	Gasoline 1.6	Expansion N(kg)	123
			Compression N(kg)	45
		Gasoline 2.0	Expansion N(kg)	133
Compression N(kg)			48	
Spring	Gasoline 1.6 (MT)		Free height	329.2
			Color code	Green - Red
	Gasoline 1.6 (AT) Gasoline 2.0 (MT/Non A/con) Diesel 1.5 (MT/Non A/con)		Free heights	336.4
			Color code	Green - Yellow
	Gasoline 2.0 (MT/A/con) Gasoline 2.0 (AT/Non A/con) Diesel 1.5 (MT/A/con)		Free heights	344.4
			Color code	Green - Brown
	Gasoline 2.0 (AT/A/con)		Free heights	349.2
			Color code	Green - Blue
	Diesel 2.0 (MT)		Free heights	355.2
			Color code	Green - Violet

GENERAL

REAR SUSPENSION SYSTEM

ITEM				SPECIFICATION		
Type				Macpherson strut		
Shock absorber	Type			Double - acting, Gas filled		
	Stroke mm			203.7		
	Expansion mm			567.2 ± 3		
	Compression mm			363.5 ± 3		
	Damping force (0.3 m/s)	Gasoline 1.6	Expansion N(kg)		94	
			Compression N(kg)		25	
Gasoline 2.0		Expansion N(kg)		99		
		Compression N(kg)		21		
Spring	4 Door		Free height		339.7	
			Color code		Green - Yellow	
	5 Door (Gasoline 1.6)		Free height		342.9	
			Color code		Green - Brown	
	5 Door (Gasoline 2.0/Diesel 1.5)		Free height		349.7	
			Color code		Green - Violet	

WHEEL AND TIRE

TYPE				SPECIFICATION		
Wheel	Size			6J x 15	6J x 16	4T x 15
	Metal			Steel/Aluminum	Aluminum	Steel
	PCD			114.3 mm		
	Off set	Aluminum		43 ± 0.5 mm		-
		Steel		43 ± 1 mm	-	30 ± 1 m
	Run out	Aluminum	Radial	0.25 mm		-
			Axial	0.25 mm		-
	Run out	Steel	Radial	1 mm		1.2mm
Axial			1 mm		1.2mm	
Tire	Size			185/65 R15, 195/60 R15, 205/50 R16		T25/70 D15
	Air pressure	Front		30 psi		60 psi
		Rear		30 psi		

WHEEL ALIGNMENT

TYPE		SPECIFICATION
Front	Camber	0° ± 30'
	Caster	2°36' ± 30'
	King pin	12°10' ± 30'
	Toe-in	0 ± 2mm
	Tread	1493 mm
Rear	Camber	-55' ± 30'
	Toe-in	4 ± 2 mm
	Tread	1479 mm

TIGHTENING TORQUE

Items	Nm	kgf-cm	lbf-ft
Wheel nut	90 ~ 110	900 ~ 1100	67 ~ 82
Castle nut	200 ~ 260	2000 ~ 2600	159 ~ 192
Front strut upper mounting nut	45 ~ 60	450 ~ 600	33 ~ 44
Front strut assembly to knuckle	130 ~ 150	1300 ~ 1500	96 ~ 111
Front strut mounting self-locking nut	50 ~ 70	500 ~ 700	37 ~ 51
Lower arm ball joint to knuckle	60 ~ 72	600 ~ 720	43 ~ 52
Lower arm bush (A) mounting bolt	130 ~ 150	1300 ~ 1500	96 ~ 111
Lower arm bush (G) mounting bolt	130 ~ 150	1300 ~ 1500	96 ~ 111
Stabilizer bar bracket mounting bolt	30 ~ 45	300 ~ 450	22 ~ 33
Stabilizer link nut	44 ~ 62	440 ~ 620	32 ~ 45
Tie rod end ball joint to knuckle	24 ~ 34	240 ~ 340	18 ~ 25
Tie rod end lock nut	50 ~ 55	500 ~ 550	37 ~ 41
Rear strut upper mounting nut	30 ~ 40	300 ~ 400	22 ~ 30
Rear strut lower mounting nut	110 ~ 130	1100 ~ 1300	81 ~ 96
Rear strut mounting self locking nut	40 ~ 55	400 ~ 550	29.6 ~ 40.7
Rear stabilizer link to stabilizer bar	35 ~ 45	350 ~ 450	26 ~ 33
Rear stabilizer bar bracket bolt	17 ~ 26	170 ~ 260	13 ~ 19
Rear suspension arm tie rod nut	50 ~ 60	500 ~ 600	37 ~ 43
Rear suspension arm mounting bolt	160 ~ 180	1600 ~ 1800	118 ~ 133
Rear cross member mounting bolt	100 ~ 120	1000 ~ 1200	74 ~ 88
Trailing arm to bracket nut	100 ~ 120	1000 ~ 1200	74 ~ 88
Trailing arm bracket to body frame	40 ~ 50	400 ~ 500	30 ~ 37
Trailing arm to rear carrier mounting nut	100 ~ 120	1000 ~ 1200	74 ~ 89

 CAUTION






Replace the self-locking nuts with new ones after removal.






GENERAL



LUBRICANTS EB9E109B

Item	Recommended lubricant	Quantity
In ball joint of lower arm	Variant R-2 grease or poly lub gly 801K	As required
In insulator bearing of strut	SAE J310a, Chassis grease (NLGI No.0 or equivalent)	As required

SPECIAL TOOLS EA3E372D

Tool (Number and Name)	Use	Illustration
09216-21000 Mount bushing remover and installer	 B1621100	Removal & installation of lower arm bushing (G) (Use with 09216-21200, 09545-02000)
09216-21200 Mount bushing remover and installer base	 B1621200	Removal & installation of the lower arm bushing (G) (Use with 09216-21100, 09545-02000)
09532-11600 Preload socket	 E3211600	Measurement of the lower arm ball joint & stabilizer link starting torque
09545-02000 Lower arm bushing remover and installer	 E4502000	Removal & installation of the lower arm bushing (G) (Use with 09216-21100, 09216-21200)
09545-11000 Ball joint remover and installer	 E4511000	Installation of the lower arm ball joint

Tool (Number and Name)	Use	Illustration
09545-21100 Ball joint dust cover installer	 E4521100	Installation of the lower arm ball joint dust cover
09552-25000 Trailing arm bushing remover and installer	 E5125000	Removal & installation of the trailing arm bushing
09551-25000 Rear suspension arm remover and installer	 EHDA140H	Removal & installation of the rear suspension arm bushing (Use with 09545-28100)
09568-34000 Ball joint puller	 E6834000	Separation of the lower arm ball joint
A-20 Strut compressor adapter	 E2038402	Compression of the rear coil spring (Use with J38402)

Tool (Number and Name)	Use	Illustration
A-50 Strut compressor adapter	 E5038402	Compression of the front coil spring (Use with J38402)
J38402 Strut spring compressor	 EHDA140K	Compression of the front & rear coil spring (Use with A-50 or A-20)

TROUBLESHOOTING EF19C57E

SYMPTOM CHART

Symptom	Suspect Area	Remedy
Squeak or grunt-noise from the front suspension, occurs more in cold ambient temperatures, more noticeable over rough roads or when turning	Front stabilizer bar	Under these conditions, the noise is acceptable.
Clunk-noise from the front suspension, occurs in and out of turns	Loose front struts or shocks	Inspect for loose nuts or bolts. Tighten to specifications.
Clunk-noise from the rear suspension, occurs when shifting from reverse to drive	Loose rear suspension components	Inspect for loose or damaged rear suspension components. Repair or install new components as necessary.
Click or pop-noise from the front suspension, more noticeable over rough roads or over bumps	Worn or damaged ball joints	Install new components as necessary.
Click or pop-noise, occurs when vehicle is turning	Worn or damaged ball joints	Install new lower arm as necessary.
Click or snap, occurs when accelerating around a corner	Damaged or worn Birfield joint	Repair or install a new Birfield joint as necessary. See DS group - driveshaft.
Front suspension noise, a squeak, creak or rattle noise, occurs mostly over bumps or rough roads	Steering components Loose or bent front struts or shock absorbers Damaged spring or spring mounts Damaged or worn arm bushings Worn or damaged stabilizer bar bushing or links	Go to detailed test A.
Groaning or grinding-noise from the front strut, occurs when driving on bumpy roads or turning the vehicle	Uneven seating surface between the insulator and panel by the burrs around the strut insulator mounting bolts and the insulator bolts mounting holes	Repair or install a new parts as necessary.
Rear suspension noise, a squeak, creak or rattle noise, occurs mostly over bumps or rough roads	Loose or bent rear shock absorbers Damaged spring or spring mounts Damaged or worn control arm bushings	Go to detailed test B.
Shudder, occurs during acceleration from a slow speed or stop	Rear axle assembly mispositioned Damaged or worn front suspension components	Check the axle mounts and Rear suspension the rear suspension for damage or wear. Repair as necessary. Check for a loose stabilizer bar, damaged or loose strut/strut bushings or loose or worn ball joints. Inspect the steering linkage for wear or damage. Repair or Install new components as necessary.
Shimmy, most noticeable on coast/deceleration, also hard steering condition	Excessive positive caster	Check the caster alignment angle. Correct as necessary.

Symptom	Suspect Area	Remedy
Tire noise, hum/moan at constant speeds	Abnormal wear patterns	Spin the tire and check for tire wear. Install a new tire as necessary. Inspect for damaged/worn suspension components. Carry out wheel alignment.
Tire noise, noise tone lowers as the vehicle speed is lowered	Out-of-balance tire	Balance the tire and road test. Install a new tire as necessary.
Tire noise, noise tone lowers as the vehicle speed is lowered	Nail puncture or stone in tire tread	Inspect the tire. Repair as necessary.
Wheel and tire-vibration and noise concern is directly related to vehicle speed and is not affected by acceleration, coasting or decelerating	Damaged or worn tire	Go to detailed test C.
Tire wobble or shudder, occurs at lower speeds	Damaged wheel bearings	Spin the tire and check for abnormal wheel bearing play or roughness. Adjust or Install new wheel bearings as necessary. See DS group - front/rear axle.
	Damaged wheel	Inspect the wheel for damage. Install a new wheel as necessary.
	Damaged or worn suspension components	Inspect the suspension components for wear or damage. Repair as necessary.
	Loose wheel nuts	Check the wheel nuts. Tighten to specification.
	Damaged or uneven tire wear	Spin the tire and check for abnormal tire wear or damage. Install a new tire as necessary.
Tire shimmy or shake, occurs at lower speeds	Wheel/tire out of balance	Balance the tire and road test. Install a new tire as necessary.
	Uneven tire wear	Check for abnormal tire wear. Install a new tire as necessary.
	Excessive radial runout of wheel or tire	Carry out a radial runout test of the wheel and tire. Install a new tire as necessary.
	Worn or damaged wheel studs or elongated stud holes	Inspect the wheel studs and wheels. Install new components as necessary.
	Excessive lateral runout of the wheel or tire	Carry out a lateral runout test of the wheel and tire. Check the wheel, tire and hub. Repair or Install new components as necessary.
	Foreign material between the brake disc and hub.	Clean the mounting surfaces of the brake disc and hub. See DS group - front/rear axle.

Symptom	Suspect Area	Remedy
High speed shake or shimmy, occurs at high speeds	Excessive wheel hub runout Damaged or worn tires Damaged or worn wheel bearings Worn or damaged suspension or steering linkage Brake disc or drum imbalance	Go to detailed test D.
Drift left or right	Tires Steering linkage Alignment Base brake system	Go to detailed test E.
Steering wheel	Alignment Steering linkage Front lower arm ball joint	Go to detailed test F.
Tracks incorrectly	Rear suspension Caster	Go to detailed test G.
Rough ride	Front strut and spring assembly Rear shock absorber and spring assembly	Go to detailed test H.
Excessive noise	Front or rear stabilizer bar components Springs Suspension components Shock absorbers	Go to detailed test I.
Incorrect tire wear	Tire or unbalanced wheels Tire inflation Strut Alignment	Go to detailed test J.
Vibration	Wheel/tire Front wheel drivshaft(s) Steering system Strut and spring assembly Spring and strut mounting Front lower arm ball joint Front lower arm mounting bolt bushing Stabilizer bar bushings Wheel hubs and bearing Rear suspension arms and bushings	Go to detailed test K.
Vehicle leans	Tire/wheel Vehicle load Suspension components Incorrect ride height	Inflate tires to specification. Redistribute the load as necessary. Visually inspect the suspension system Correct the ride height as necessary
Poor returnability	High knuckle rotating torque Alignment	Go to detailed test E.

DETAILED TEST A : FRONT SUSPENSION NOISE

CONDITIONS	DETAILS/RESULTS/ACTIONS
A1 ROAD TEST THE VEHICLE	
	<p>1. Test drive the vehicle. 2. During the road test, drive the vehicle over a rough road. Determine from which area/component the noise is originating.</p> <p>Is there a squeak, creak or rattle noise ?</p> <p>⇒ YES Go to A2.</p> <p>⇒ NO The suspension system is OK. Conduct a diagnosis on other suspect systems.</p>
A2 INSPECT THE STEERING SYSTEM	
	<p>1. Check the steering system for wear or damage. Carry out a steering linkage test. 2. Inspect the tire wear pattern. See page SS-24.</p> <p>Are the steering components worn or damaged ?</p> <p>⇒ YES Repair the steering system. Install new components as necessary. Test the system for normal operation</p> <p>⇒ NO Go to A3.</p>
A3 FRONT SHOCK ABSORBER/STRUT CHECK	
	<p>1. Check the front shock absorbers/strut mounts for loose bolts or nuts. 2. Check the front shock absorbers/struts for damage. Carry out a shock absorber check.</p> <p>Are the front shock absorbers/struts loose or damaged ?</p> <p>⇒ YES Tighten to specifications if loose. Install new front shock absorbers/struts if damaged. Test the system for normal operation.</p> <p>⇒ NO Go to A4.</p>
A4 CHECK THE FRONT SPRINGS	
	<p>Check the front spring and front spring mounts/brackets for wear or damage</p> <p>Are the front springs or spring mounts/brackets worn or damaged ?</p> <p>⇒ YES Repair or Install new components as necessary. Test the system for normal operation.</p> <p>⇒ NO Go to A5.</p>


CONDITIONS	DETAILS/RESULTS/ACTIONS
A5 CHECK THE STABILIZER BAR	
	<ol style="list-style-type: none">1. Check the stabilizer bar bushing and links for damage or wear.2. Check the stabilizer bar for damage.3. Check for loose or damaged stabilizer brackets. <p>Are the stabilizer bar/track bar components loose, worn or damaged ?</p> <p>⇒ YES Repair or Install new components as necessary. Test the system for normal operation.</p> <p>⇒ NO Suspension system is OK. Conduct diagnosis on other suspect systems.</p>

DETAILED TEST B : REAR SUSPENSION NOISE

CONDITIONS	DETAILS/RESULTS/ACTIONS
B1 ROAD TEST THE VEHICLE	
	<ol style="list-style-type: none">1. Test drive the vehicle.2. During the road test, drive the vehicle over a rough road. Determine from which area/component the noise is originating. <p>Is there a squeak, creak or rattle noise ?</p> <p>⇒ YES Go to B2.</p> <p>⇒ NO The suspension system is OK. Conduct a diagnosis on other suspect systems.</p>
B2 REAR SHOCK ABSORBER/STRUT CHECK	
	<ol style="list-style-type: none">1. Raise and support the vehicle. See GI group - lift support point.2. Check the rear shock absorber/strut mounts for loose bolts or nuts.3. Check the rear shock absorbers/strut for damage. Carry out a shock absorber check. <p>Are the rear shock absorbers/struts loose or damaged ?</p> <p>⇒ YES Tighten to specifications if loose. Install new rear shock absorbers/struts if damaged. Test the system for normal operation.</p> <p>⇒ NO Goto B3.</p>

B3 CHECK THE REAR SPRINGS	
	<p>Check the rear springs and rear spring mounts/brackets for wear or damage.</p> <p>Are the rear springs or spring mounts/brackets worn or damaged ?</p> <p>⇒ YES Repair or Install new components as necessary. Test the system for normal operation.</p> <p>⇒ NO Go to B4.</p>
B4 CHECK THE TRAILING ARMS	
	<ol style="list-style-type: none">1. Inspect the trailing arm bushings for wear or damage. Check for loose trailing arm bolts.2. Inspect for twisted or bent trailing arms. <p>Are the trailing arms loose, damaged or worn ?</p> <p>⇒ YES Repair or Install new components as necessary. Test the system for normal operation.</p> <p>⇒ NO Suspension system is OK. Conduct diagnosis on other suspect systems.</p>

DETAILED TEST C : WHEEL AND TIRE

CONDITIONS	DETAILS/RESULTS/ACTIONS
C1 ROAD TEST THE VEHICLE	
	<p> NOTE</p> <p><i>Wheel or tire vibrations felt in the steering wheel are most likely related to the front wheel or tire. Vibration felt through the seat are most likely related to the rear wheel or tire. This may not always be true, but it can help to isolate the problem to the front or rear of the vehicle. Test drive the vehicle at different speed ranges.</i></p> <p>During the road test, if the vibration can be eliminated by placing the vehicle in neutral or is affected by the speed of the engine, the cause is not the wheels or tires.</p> <p>Is there a vibration and noise ?</p> <p>⇒ YES Go to C2.</p> <p>⇒ NO The wheel and tires are OK. Conduct a diagnosis on other suspect systems.</p>

C2 CHECK THE FRONT WHEEL BEARINGS	
	<p>Check the front wheel bearings. Refer to Wheel Bearing Check (See DS group - front axle).</p> <p>Are the wheel bearing OK ?</p> <p>⇒ YES Go to C3.</p> <p>⇒ NO Inspect the wheel bearings. Adjust or Repair as necessary. Test the system for normal operation.</p>
C3 INSPECT THE TIRES	
	<ol style="list-style-type: none">1. Check the tires for missing weights.2. Check the wheels for damage.3. Inspect the tire wear pattern. See page SS-24. <p>Do the tires have an abnormal wear pattern ?</p> <p>⇒ YES Correct the condition that caused the abnormal wear. Install new tire(s). Test the system for normal operation.</p> <p>⇒ NO Go to C4.</p>
C4 TIRE ROTATION DIAGNOSIS	
	<ol style="list-style-type: none">1. Spin the tires slowly and watch for signs of lateral runout.2. Spin the tires slowly and watch for signs of radial runout. <p>Are there signs of visual runout ?</p> <p>⇒ YES Go To C5.</p> <p>⇒ NO Check the wheel and tire balance. Correct as necessary. Test the system for normal operation.</p>
C5 RADIAL RUNOUT CHECK ON THE TIRE	
	<p>Measure the radial runout of the wheel and tire assembly. A typical specification for total radial runout is 1.15mm (0.045 inch).</p> <p>Is the radial runout within specifications ?</p> <p>⇒ YES Go to C8.</p> <p>⇒ NO Go to C6.</p>

C6 RADIAL RUNOUT CHECK ON THE WHEEL	
	<p>Measure the radial runout of the wheel. A typical specification for total radial runout is 1.14mm (0.045 inch.).</p> <p>Is the radial runout within specifications ?</p> <p>⇒ YES Install a new tire. Test the system for normal operation.</p> <p>⇒ NO Go to C7.</p>
C7 CHECK THE HUB/BRAKE DISC OR DRUM PILOT RUNOUT OR BOLT CIRCLE RUNOUT	
	<p>Measure the pilot or bolt circle runout. A typical specification for radial runout is :</p> <p>pilot runout - less than 0.15mm (0.006 inch.) bolt circle runout - less than 0.38 mm (0.015 inch.)</p> <p>Is the radial runout within specification ?</p> <p>⇒ YES Install a new wheel. Test the system for normal operation.</p> <p>⇒ NO Repair or Install new components as necessary.</p>
C8 LATERAL RUNOUT CHECK ON THE TIRE	
	<p>Measure the lateral runout of the wheel and tire assembly. A typical specification for total lateral runout is 2.5mm (0.098 inch).</p> <p>Is the lateral runout within specifications ?</p> <p>⇒ YES Wheel and tires are OK. Conduct diagnosis on other suspect systems.</p> <p>⇒ NO Go to C9.</p>
C9 LATERAL RUNOUT CHECK ON THE WHEEL	
	<p>Measure the lateral runout of the wheel. A typical specification for radial runout is 1.2mm (0.047 inch.)</p> <p>Is the lateral runout within specifications ?</p> <p>⇒ YES Install a new tire. Test the system for normal operation.</p> <p>⇒ NO Go to C10.</p>

C10 CHECK THE FLANGE FACE LATERAL RUNOUT	
	<p>Measure the flange face lateral runout. A typical specification for lateral runout is :</p> <p>hub/brake disc - less than 0.13mm (0.005 inch)</p> <p>Is the lateral runout within specifications ?</p> <p>⇒ YES Install a new wheel. Test the system for normal operation.</p> <p>⇒ NO Repair or Install new components as necessary.</p>

DETAILED TEST D : HIGH SPEED SHAKE OR SHIMMY

CONDITIONS	DETAILS/RESULTS/ACTIONS
D1 CHECK FOR FRONT WHEEL BEARING ROUGHNESS	
	<ol style="list-style-type: none">1. See GI group - lift support point.2. Spin the front tires by hand. <p>Do the wheel bearings feel rough ?</p> <p>⇒ YES Inspect the wheel bearings. Repair as necessary. Test the system for normal operation.</p> <p>⇒ NO Go to D2.</p>
D2CHECK THE END PLAY OF THE FRONT WHEEL BEARINGS	
	<p>Check the end play of the front wheel bearings.</p> <p>Is the end play OK ?</p> <p>⇒ YES Go to D3.</p> <p>⇒ NO Adjust or Repair as necessary. Test the system for normal operation.</p>
D3 MEASURE THE LATERAL RUNOUT AND THE RADIAL RUNOUT OF THE FRONT WHEELS ON THE VEHICLE	
	<p>Measure the lateral runout and the radial runout of the front wheels on the vehicle. Go to detailed test C.</p> <p>Are the measurements within specifications ?</p> <p>⇒ YES Go to D4.</p> <p>⇒ NO Install new wheels as necessary and Balance the assembly. Test the system for normal operation.</p>

D4 MEASURE THE LATERAL RUNOUT OF THE FRONT TIRES ON THE VEHICLE	
	<p>Measure the lateral runout of the front tires on the vehicle. Go to detailed test C.</p> <p>Is the runout within specifications ?</p> <p>⇒ YES Go to D5.</p> <p>⇒ NO Install new tires as necessary and Balance the assembly. Test the system for normal operation.</p>
D5 MEASURE THE RADIAL RUNOUT OF THE FRONT TIRES ON THE VEHICLE	
	<p>Measure the radial runout of the front tires on the vehicle. Go to detailed test C.</p> <p>Is the runout within specifications ?</p> <p>⇒ YES Balance the front wheel and tire assemblies. If any tire cannot be balanced, Install a new tire. Test the system for normal operation.</p> <p>⇒ NO Go to D6.</p>
D6 MATCH MOUNT THE TIRE AND WHEEL ASSEMBLY	
	<p>Mark the high runout location on the tire and also on the wheel. Break the assembly down and rotate the tire 180 degrees(halfway around) on the wheel. Inflate the tire and measure the radial runout.</p> <p>Is the runout within specifications ?</p> <p>⇒ YES Balance the assembly. Test the system for normal operation.</p> <p>⇒ NO If the high spot is not within 101.6mm (4 inch) of the first high spot on the tire, Go to D7</p>
D7 MEASURE THE WHEEL FLANGE RUNOUT	
	<p>Dismount the tire and mount the wheel on a wheel balancer. Measure the runout on both wheel flanges. Go to detailed test C.</p> <p>Is the runout within specifications ?</p> <p>⇒ YES Locate and Mark the low spot on the wheel. Install the tire, matching the high spot on the tire with the low spot on the wheel. Balance the assembly. Test the system for normal operation. If the condition persists, Go to D8.</p> <p>⇒ NO Install a new wheel. Check the runout on the new wheel. If the new wheel is within limits, locate and Mark the low spot. Install the tire matching the high spot on the tire with the low spot on the wheel. Balance the assembly. Test the system for normal operation. If the condition persists, Go to D8.</p>

D8 CHECK FOR VIBRATION FROM THE FRONT OF THE VEHICLE

Spin the front wheel and tire assemblies with a wheel balancer while the vehicle is raised on a hoist. Feel for vibration in the front fender or while seated in the vehicle.

Is the vibration present ?

⇒ **YES**

Substitute known good wheel and tire assemblies as necessary. Test the system for normal operation.

⇒ **NO**

Check the driveline components. Test the system for normal operation.

DETAILED TEST E : DRIFT LEFT OR RIGHT

CONDITIONS	DETAILS/RESULTS/ACTIONS
E1 CHECK THE TIRES	
	<p>Inspect the tires for excessive wear or damage.</p> <p>Are the tires excessively worn or damaged ?</p> <p>⇒ YES Install new tires.</p> <p>⇒ NO Go to E2.</p>
E2 CHECK THE STEERING LINKAGE	
	<ol style="list-style-type: none">1. Raise and support the vehicle.2. Check the steering components for indications of excessive wear or damage. See ST group - specification. <p>Is there an indication of excessive wear or damage ?</p> <p>⇒ YES Repair or Install new components as necessary.</p> <p>⇒ NO Go to E3.</p>
E3 CHECK THE VEHICLE ALIGNMENT	
	<ol style="list-style-type: none">1. Place the vehicle on an alignment rack. Check the vehicle alignment. <p>Is the alignment within specification ?</p> <p>⇒ YES Go to E4.</p> <p>⇒ NO Adjust the alignment as necessary.</p>

CONDITIONS	DETAILS/RESULTS/ACTIONS
E4 BRAKE DRAG DIAGNOSIS	
	Apply the brakes while driving. Does drift or pull occur when the brakes are applied ? ⇒ YES See BR group - specification. ⇒ NO If the steering wheel is in the center, the vehicle is OK. If the steering wheel is off-center, GO to Detailed Test F.

DETAILED TEST F : STEERING WHEEL OFF-CENTER

CONDITIONS	DETAILS/RESULTS/ACTIONS
F1 CHECK THE CLEAR VISION	
	Place the vehicle on an alignment rack. Is the clear vision within specification ? ⇒ YES Go to F2. ⇒ NO Adjust the clear vision to specification.
F2 INSPECT THE STEERING COMPONENTS	
	1. Raise and support the vehicle. 2. Inspect the steering components for excessive wear or damage. See ST group - specification. Are the steering components excessively worn or damaged ? ⇒ YES Repair or Install new components as necessary. ⇒ NO If it tracks correctly, vehicle is OK. If it tracks incorrectly, Go to Detailed Test G.

DETAILED TEST G : TRACKS INCORRECTLY

CONDITIONS	DETAILS/RESULTS/ACTIONS
G1 CHECK THE CASTER	
	Place the vehicle on an alignment rack. Are the caster within specification ? ⇒ YES Go to G2. ⇒ NO

CONDITIONS	DETAILS/RESULTS/ACTIONS
G2 CHECK THE REAR SUSPENSION	
	<ol style="list-style-type: none">1. Measure the vehicle wheel base for LH and RH.2. Compare the measurements. <p>Are the measurements the same ?</p> <p>⇒ YES If the ride is smooth, vehicle is OK.</p> <p>If the ride is rough, Go to Detailed Test H.</p> <p>⇒ NO Inspect the rear suspension components for wear or damage. Repair or Install new components as necessary.</p>

DETAILED TEST H : ROUGH RIDE

CONDITIONS	DETAILS/RESULTS/ACTIONS
H1 CHECK THE FRONT SHOCK ABSORBER	
	<ol style="list-style-type: none">1. Raise support the vehicle.2. Inspect the front shock absorber for oil leaks or damage. <p>Are the tires excessively worn or damaged ?</p> <p>⇒ YES Install new front shock absorbers.</p> <p>⇒ NO Go to H2.</p>
H2 CHECK THE REAR SHOCK ABSORBERS	
	<p>Inspect the rear shock absorbers for oil leaks or damage.</p> <p>Are the rear shock absorbers leaking ?</p> <p>⇒ YES Install new rear shock absorbers.</p> <p>⇒ NO The vehicle is OK. Go to TROUBLESHOOTING.</p>

DETAILED TEST I : EXCESSIVE NOISE

CONDITIONS	DETAILS/RESULTS/ACTIONS
I1 INSPECT THE SUSPENSION	
	<ol style="list-style-type: none">1. Raise and support the vehicle.2. Inspect the shock absorber mounting bolts. <p>Are the mounting bolts loose or broken ?</p> <p>⇒ YES Tighten or Install new shock absorber mounting bolts.</p> <p>⇒ NO Go to I2.</p>
I2 INSPECT THE SPRING AND TORSION BARS	
	<p>Inspect the springs and stabilizer bars for damage.</p> <p>Are the spring or stabilizer bars damaged ?</p> <p>⇒ YES Install new spring and/or stabilizer bars.</p> <p>⇒ NO Go to I3.</p>
I3 INSPECT THE FRONT SUSPENSION	
	<p>Inspect the front suspension components for excessive wear or damage.</p> <p>Are the front suspension components worn or damaged ?</p> <p>⇒ YES Install new front suspension components.</p> <p>⇒ NO The vehicle is OK. Go to TROUBLESHOOTING.</p>

DETAILED TEST J : INCORRECT TIRE WEAR

CONDITIONS	DETAILS/RESULTS/ACTIONS
J1 INSPECT THE TIRES	
	<ol style="list-style-type: none">1. Raise and support the vehicle.2. Inspect the tires for uneven wear on the inner or outer shoulder. <p>Is there uneven tire wear ?</p> <p>⇒ YES Align the vehicle. Install new tires if badly worn.</p> <p>⇒ NO Go to J2.</p>

J2 UNEVEN TIRE WEAR	
	<p>Inspect the tires for a feathering pattern.</p> <p>Do the tires have a feathering pattern ?</p> <p>⇒ YES Align the vehicle. Install new tires if badly worn.</p> <p>⇒ NO Go to J3.</p>
J3 CHECK FOR CUPPED TIRE	
	<p>Inspect the tires for cupping or dishing.</p> <p>Are the tires cupped or dished ?</p> <p>⇒ YES Balance and Rotate the tires.</p> <p>⇒ NO The vehicle is OK. Go to TROUBLESHOOTING.</p>

DETAILED TEST K : VIBRATION







CONDITIONS	DETAILS/RESULTS/ACTIONS
K1 ROAD TEST	
	<p>Accelerate the vehicle to the speed at which the customer indicated the vibration occurred.</p> <p>Is the vibration present ?</p> <p>⇒ YES Go to K2.</p> <p>⇒ NO The vehicle is OK. Go to TROUBLESHOOTING.</p>
K2 INSPECT THE TIRES	
	<ol style="list-style-type: none">1. Raise and support the vehicle with a frame contact hoist.2. Inspect the tires for extreme wear or damage, cupping, or flat spots. <p>Are the tires OK ?</p> <p>⇒ YES Go to K3.</p> <p>⇒ NO Check the suspension components for misalignment, abnormal wear, or damage that may have contributed to the tire wear. Correct the suspension concerns and Install new tires.</p>

K3 INSPECT THE WHEEL BEARINGS	
	<p>Spin the tires by hand to check for wheel bearing roughness.</p> <p>Is the front wheel bearing OK ?</p> <p>⇒ YES Go to K4.</p> <p>⇒ NO Install new front wheel bearings as necessary. See DS group - front axle.</p>
K4 TIRE/WHEEL BALANCE	
	<p>Check the tire/wheel balance.</p> <p>Are the tires balanced ?</p> <p>⇒ YES Go to K5.</p> <p>⇒ NO Balance the tires and wheels as necessary.</p>
K5 MEASURE THE RUNOUTS	
	<p>For each wheel position measure, locate and mark the following items.</p> <ul style="list-style-type: none">- High point of the tire/wheel assembly total radial runout- High point of the wheel radial runout- High point of the wheel lateral runout <p>Are the runouts as specified ?</p> <p>⇒ YES Go to K7.</p> <p>⇒ NO Go to K6.</p>
K6 SUBSTITUTE THE WHEELS AND TIRE	
	<ol style="list-style-type: none">1. Substitute a known good set of wheels and tires.2. Carry out a road test.3. If the vehicle still exhibits a shake or vibration, note the vehicle speed and/or engine rpm which it occurs. <p>Is the vibration felt ?</p> <p>⇒ YES Engine/transmission imbalance. See the specification of TR group, EM group, FL group and EC group.</p> <p>⇒ NO Install the original tire/wheel assemblies one by one, Road testing at each step until the damaged tire(s)/wheel(s) as necessary. Test the system for normal operation.</p>

Wheel/tire noise, vibration and harshness concerns are directly related to vehicle speed and are not generally affected by acceleration, coasting or decelerating. Also, out-of-balance wheel and tires can vibrate at more than one speed. A vibration that is affected by the engine rpm, or is eliminated by placing the transmission in Neutral is not related to the tire and wheel. As a general rule, tire and wheel vibrations felt in the steering wheel are related to the front tire and wheel assemblies. Vibrations felt in the seat or floor are related to the rear tire and wheel assemblies. This can initially isolate a concern to the front or rear.


Careful attention must be paid to the tire and wheels. There are several symptoms that can be caused by damaged or worn tire and wheels. Carry out a careful visual inspection of the tires and wheel assemblies. Spin the tires slowly and watch for signs of lateral or radial runout. Refer to the tire wear chart to determine the tire wear conditions and actions.

WHEEL AND TIRE DIAGNOSIS

<p>Rapid wear at the center</p>	<p>Rapid wear bat both shoulders</p>	<p>Wear at one shoulder</p>
 <p style="text-align: right;">KXDT001A</p>	 <p style="text-align: right;">KXDT002A</p>	 <p style="text-align: right;">KXDT003A</p>
<ul style="list-style-type: none"> • Center-tread down to fabric due to excessive over inflated tires • Lack of rotation • Excessive toe on drive wheels • Heavy acceleration on drive 	<ul style="list-style-type: none"> • Underinflated tires • Worn suspension components • Excessive cornering speeds • Lack of rotation 	<ul style="list-style-type: none"> • Toe adjustment out of specification • Camber out of specification • Damaged strut • Damaged lower arm
<p>Partial wear</p>	<p>Feather edges wheels</p>	<p>Wear pattern</p>
 <p style="text-align: right;">KXDT004A</p>	 <p style="text-align: right;">KXDT005A</p>	 <p style="text-align: right;">KXDT006A</p>
<ul style="list-style-type: none"> • Cansed by irreqular burrs on brak drums. 	<ul style="list-style-type: none"> • Toe adjustment out of specification • Damaged or worn tie rods • Damaged knuckle 	<ul style="list-style-type: none"> • Excessive toe on non-drive wheels • Lack of rotation

FRONT SUSPENSION SYSTEM

COMPONENTS ECA8C84D



- | | |
|--|-------------------------------------|
| 1. Strut insulator dust cover | 7. Lower arm |
| 2. Front strut upper mounting nut | 8. Front stabilizer bar link |
| 3. Front strut assembly | 9. Sub frame |
| 4. Lower arm bushing (G) mounting bolt | 10. Lower arm bushing(A) |
| 5. Tie rod | 11. Front stabilizer bar |
| 6. Knuckle assembly | 12. Front strut lower mounting bolt |

DESCRIPTION E7C387AC

The front suspension system consists of the following components.

- Front strut assemblies
- Front lower arm assemblies
- Front stabilizer bar and links

The front strut and spring assemblies can be disassembled to install any of the new individual components. New LH or RH front strut and spring assemblies can be installed independently.


The front suspension system can also be disassembled in order to install new.

- Front lower arms
- Front lower arm mounting bolt bushings

New front stabilizer bar components can be installed individually.

STRUT ASSEMBLY

COMPONENTS EF69BE2D



- 1. Front strut upper mounting nuts
- 2. Insulator dust cover
- 3. Front strut self-locking nut
- 4. Strut insulator
- 5. Spring upper seat
- 6. Strut dust cover

- 7. Rubber bumper
- 8. Front coil spring
- 9. Spring lower pad
- 10. Piston rod
- 11. Front strut assembly
- 12. Spring lower seat


EXDSE01A

REMOVAL EB2F1D32

1. Remove the front wheel and tire.
2. Detach the brake hose bracket(B) from the front strut assembly(A).


NOTE

Do not apply excessive force to the components.




KXDSE02A

3. In case of the vehicles equipped with Anti-lock Brake system, remove the wheel speed sensor(A) from the knuckle(B).




EIKE107A

4. Remove the strut upper mounting nuts(A).



EXDSE04A


5. Remove the strut lower mounting bolts(A) and then remove the strut assembly(B).



KXDSE05A


DISASSEMBLY E02DCBBB

1. Remove the dust cover(A) with a flat-tipped (-) screwdriver(B).




EXDSE06A

2. Open the dust cover and wipe off grease in the insulator.



KXDSE07A

3. Using the Special Tool (J38402, A-50), compress the coil spring(A) until there is only a little tension of the spring on the strut.




KXDSE08A

NOTE

- When compress the coil spring, do not use an impact gun.

4. Under the condition of fixed strut(A) on the vise(B), remove the front strut self-locking nut(C).




KXDSE10A

5. Remove the insulator, spring seat, coil spring and dust cover from the strut assembly

INSPECTION ECC05CAD

1. Check the strut insulator bearing for wear or damage.
2. Check rubber parts for damage or deterioration.
3. Compress and extend the piston rod(A) and check that there is no abnormal resistance or unusual sound during operation.




KXDSE11A

REPLACEMENT E2B6494E

1. Fully extend the piston rod.
2. Drill a hole on the A section to remove gas from the cylinder.

 **CAUTION**

The gas coming out is harmless, but be careful of chips that may fly when drilling.




KXDSE01B

REASSEMBLY EC4F7FBA

1. Install lower spring pad so that the protrusions fit in the holes of the spring lower seat.
2. Install the strut dust cover(A) and rubber bump(B) to piston rod.

 **CAUTION**

Compress the piston rod until engaging two grooves(A,B).



KXDSE12A

3. Compress coil spring using Special tool (J38402, A-50).
Install compressed coil spring into shock absorber.


 **NOTE**

1. Indicated two identification color marks on the coil spring; one follows model option (see page SS-2) the other follows load classification according to the below.
Pay attention to distinguish between the two marks and then install them.

Left wheel side(LH)		Right wheel side(RH)
WHITE	←————→	WHITE
YELLOW	←————→	YELLOW
RED	←————→	RED

EHKE004A

2. Install the coil spring with the identification mark directed toward the knuckle.
4. After fully extending the piston rod, install the spring upper seat and insulator assembly.
5. After seating the upper and lower ends of the coil spring(A) in the upper and lower spring seat grooves(B) correctly, tighten new self-locking nut temporarily.



EHKD010A

6. Remove the Special Tool(J38402, A-50).
7. Tighten the self-locking nut to the specified torque.

Tightening torque

50~70 Nm (500~700 kgf.cm, 37~51 lbf.ft)

8. Apply grease to the strut upper bearing and install the insulator cap.

 **CAUTION**

When applying the grease, be careful so that it isn't smeared on the insulator rubber.

INSTALLATION E8A30BCF


1. Installation is the reverse of the removal procedure.

 **NOTE**

After installation, check the front wheel alignment.

LOWER ARM

COMPONENTS E4C464DC



- | | |
|----------------------------|---|
| 1. Sub-frame | 6. Lower arm ball joint mounting |
| 2. Stabilizer bar | 7. Sub frame and lower arm bush(A) mounting bolts |
| 3. Tie-rod | 8. Lower arm assembly |
| 4. Front strut | 9. Sub frame and lower arm bush(G) mounting bolt |
| 5. Stabilizer bar link nut | |


EXDSE20A

FRONT SUSPENSION SYSTEM

SS -33


REMOVAL EE8A7B66

1. Remove the front wheel and tire.
2. Remove the split pin, the castle nut and the washer.
3. Loosen the lower arm ball joint nut(A), but do not remove it.




KXDSE13A

4. Remove the front strut lower mounting bolts(A) from the strut assembly(B).




KXDSE05A

5. Push the axle hub(A) outward to install the Special tool (09568-34000) easily.




KXDSE14A

6. Using the Special Tool (09568 - 34000), disconnect the lower arm ball joint(C) from the lower arm(B).



KXDSE14B

7. Remove the stabilizer link nut(A).




KXDSE15A


8. Temporarily install the strut lower mounting bolt.
9. To the lower arm mounting bolt, remove the passenger seat side cover(A).

NOTE

It can be easily removed by loosening the mounting bolts(B).




KXDSE19A




KXDSE16A

11. Remove the lower arm assembly after completely unfastening the nut of lower arm ball joint which was loosened temporarily in step 3.

10. Remove the lower arm mounting bolts(A,B,C).



KXDSE17A



KXDSE18A

INSPECTION E74E9ED2

1. Check the bushing for wear and deterioration.
2. Check the lower arm for bending or breakage.
3. Check the ball joint dust cover for cracks and damage.
4. Check all bolts for damage and deformation.
5. Measure the ball joint rotating torque.


Standard value

2~3.5 Nm (20~35 kgf.cm, 1.4~2.5 lbf.ft)


- If the rotating torque is exceeds the limit of the standard value, replace the ball joint assembly.
- Even if the rotating torque is below the lower limit of the standard value, the ball joint may be reused unless it has drag and excessive play.

NOTE

Measure torque using the special tool (09532-11600) and torque wrench(B) at the range of 0.5~2 rpm after moving the ball joint stud(A) 3° several times at room temperature.



EHKD008A




EHKD009A

REPLACEMENT E0DB37E3


BALL JOINT AND DUST COVER

1. Using a flat-tipped (-) screwdriver(A), remove the dust cover(C) from the lower arm ball joint(B).




KHKD003A

2. Remove the snap ring(A).




KXDSE21A




KXDSE22A

- Using a plastic hammer or the Special tool(09545-3A000), separate the ball joint(B) from the lower arm(A).




KXDSE23A

- Using the Special tool (09545 - 11000A/B), press-fit the ball joint into the lower arm assembly(A).



KXDSE24A


- Install the snap ring.
- Using the Special tool (09545 - 21100), install the dust cover.



EHKD001A


LOWER ARM BUSHING (G)

- Install the Special tools (09545 - 02000, 09216 - 21200, 09216 - 21200) on the lower arm.
- Press out the bushing.



EHKD102B

- Apply soap solution to the following parts.
 - Outer surface of the bushing.
 - Inner surface of the lower arm bushing mounting part.
- Install the new bushing on the lower arm using the Special Tools (09216 - 21100, 09624 - 34000).




EHKD102A

 **NOTE**

Press-in the lower arm bushing (G) in the same direction as shown in illustration.

Pull out force for the bushing :
80 N [800 kg(f), 11.9 lb(f)] or more




EXDSS55A

INSTALLATION ED4B8F78

Installation is the reverse of the removal procedure.

FRONT STABILIZER BAR

COMPONENTS E2ABBC8A




- 1. Front stabilizer bar bracket mounting bolts
- 2. Front stabilizer bar bracket
- 3. Front stabilizer bar bushing
- 4. Front stabilizer bar

- 5. Front stabilizer bar link nuts
- 6. Lower arm assembly
- 7. Front stabilizer bar link

EXDSE25A


REMOVAL E99D1BFE

1. Remove the front wheel and tire.
2. Remove the stabilizer bar link assembly (A).



KXDSE27A

3. Remove the stabilizer bracket(A) and bushing(B)
 - a. After loosen the bolts(C-in case of LH, separate pad by loosening the fixing bolts of the stabilizer bar bracket), then remove the bracket(A) and bushing(B)




KXDSE28A

- a. Remove the bolts(B) and stabilizer bar link(A).

NOTE

If the stabilizer bar link ball joint(C) and nuts(B) turn together, use the pentagonal wrench to hold the stud.

- b. Remove the stabilizer bar link on the opposite side in the same way.
- c. Remove the stabilizer out of the vehicle's right side.



KXDSE26A


- b. Remove the stabilizer bar link on the opposite side in the same way.

CAUTION

Be careful not to damage the ball joint boot.

INSPECTION EF300E0A

1. Check the stabilizer bar for deterioration and damage.
2. Check all bolts for damage and deformation.
3. Check the stabilizer link dust cover for cracks or damage.
4. Check the stabilizer link ball joint(A) for rotating torque.



EHKD007A

- If there is a crack in the dust cover, replace it and add grease.
- Shake the stabilizer link ball joint stud several times.
- Mount the self-locking nut on the ball joint, and then measure the ball joint rotating torque.

Standard value

1.7~3.2 Nm (17~32 kgf·cm, 15~27 lbf·in)


- If the rotating torque is higher than the upper limit of the standard value, replace the stabilizer link.
- If the rotating torque is below the lower limit of the standard value, the ball joint may be reused unless it has drag and excessive play.

INSTALLATION ECB0CFFD

1. Install the bushing on the stabilizer bar.

 **NOTE**

The distance between the bushing, and the part to which white paint is applied, must continue 10mm outside the vehicle.




EXDSS53B

2. Install the bracket on the bushing
3. Align and install the bushing with the white paint on the stabilizer bar. After tightening the bolts of the bushing bracket temporarily, install the bushing bracket on the opposite side.

REAR SUSPENSION SYSTEM

COMPONENTS E7370DC7



- | | |
|--|--|
| 1. Rear strut insulator | 9. Rear suspension front arm |
| 2. Rear strut upper mounting nut | 10. Rear suspension rear arm |
| 3. Rear strut assembly | 11. Tie rod adjusting nuts |
| 4. Rear strut lower mounting bolt | 12. Rear suspension arm-cross member mounting bolt |
| 5. Carrier assembly | 13. Rear crossmember |
| 6. Trailing arm | 14. Rear stabilizer link |
| 7. Trailing arm-carrier mounting bolt | 15. Rear stabilizer bar |
| 8. Rear suspension arm-carrier mounting bolt | |

DESCRIPTION E72B82F5

The rear suspension system consists of the following components.


- Rear strut assemblies
- Rear stabilizer bar assembly
- Rear suspension arms
- Rear cross member

- Trailing arms

The rear suspension arms can be installed individually.

REAR SUSPENSION ARM

COMPONENTS EB78C97E




- 1. Rear crossmember
- 2. Rear suspension front arm
- 3. Rear suspension arm to cross member bolts
- 4. Cup

- 5. Rear suspension arm to carrier bolts
- 6. Rear cross member mounting bolts
- 7. Bracket
- 8. Rear suspension rear arm


REMOVAL EEF8977B

1. Remove the bolt (C) fixing the trailing arm (A) to the rear carrier (B).



KXDSE43A

2. Remove the bolt (C) fixing the rear suspension arm (A) to the rear carrier (B).




KXDSE44A

3. Employ the same manner described above step 1 and step 2 to the other side.

4. After supporting the rear cross member assembly (B) with a jack (A), remove the two cross member fixing bolts (C). Employ the same manner described above to the other side.


 CAUTION

The rear cross member assembly (B) is unstable on the jack(A); be careful not to allow it to fall.



KXDSE45A

5. Lowering the jack, remove the rear cross member and rear suspension arms as an assembly.
6. Remove the two rear suspension arm-to-cross member bolts (A, B).




KXDSE47A

7. Remove the rear suspension arms.

INSTALLATION E4ED6C82


1. Installation is in the reverse order of removal.
2. Reassemble the rear suspension arms (C) and the rear cross member (A) as shown below. Make sure that the arrow mark (B) on the rear cross member (A) should place the front face of the vehicle.
Rear suspension arm (C) -to-rear carrier bolts should be temporarily tightened, and then fully tightened with the vehicle on the ground in unloaded condition.



KXDSE46A

REAR STRUT


COMPONENTS EFCE2B16




- | | |
|----------------------------|----------------------------------|
| 1. Rear seal cushion | 8. Rear strut upper mounting nut |
| 2. Rear seatback | 9. Rear strut insulator |
| 3. Rear wheel and tire | 10. Rear strut dust cover |
| 4. Rear side seatback | 11. Rubber bumper |
| 5. Insulator dust cover | 12. Spring |
| 6. Self-locking flange nut | 13. Spring lower pad |
| 7. Pipe | 14. Rear strut assembly |

REMOVAL ECDBD924

1. Remove the rear seat (See BD group - rear seat).
 - 1) Raise the rear cushion.
 - 2) Remove the mounting bolts between rear cushion and rear seatback.
 - 3) Remove the mounting bolts to both end part of rear seatback.
2. Remove the rear strut upper mounting nuts(A).




KXDSE32A




KXDSE30A

5. After unfastening stabilizer bar link nut(C), remove the stabilizer bar link(B) from the strut(A).




KXDSE33A

3. Remove the rear wheel and tire.
4. Disconnect the brake hose(B) and wheel speed sensor wiring(C) from the rear strut(A).
 - 1) Disconnect the brake hose(B) by removing the clip(D)



KXDSE31A

6. Remove the lower strut mounting bolts(A).



KXDSE34A

- 2) Disconnect the wheel speed sensor wiring(A).



CAUTION

Be careful not to drop the rear strut.


7. Remove the rear strut assembly.

DISASSEMBLY E09C3E02

1. Using the Special Tools (J38402, A-20 and A-50), compress the coil spring(A) until there is only a little tension on the strut(B).

 **CAUTION**

Do not use an impact gun.




EXDSE35A

2. Open the insulator dust cover and then remove the self-locking nut at the top end of the upper strut.
3. Remove the spring upper seat, coil spring, spring lower pad, rubber bumper and dust cover.

INSPECTION E5F389F7


1. Check the strut insulator for wear or damage.
2. Check rubber parts for damage or deterioration.
3. Check the coil spring and strut assembly for sagging and deformation.
4. Compress and extend the piston rod(A) and check that there is no abnormal resistance or unusual sound during operating.



EXDSE36A

REASSEMBLY E264CC0F

1. Install the spring lower pad(D) so that the protrusions(A) fit in the holes(C) in the spring lower seat(B).




EHKD006A

2. Install the dust cover and rubber bump at the strut.
3. Using the Special Tools (J38402, A-20 and A-50), compress the coil spring(A).



CAUTION

Do not use an impact gun.



EXDSE35B


4. After extending the piston rod fully, install the compressed coil spring.
5. After seating the upper and lower ends of the coil spring in the upper and lower spring seat grooves correctly, tighten the new self-locking nut temporarily.



CAUTION

Replace the self-locking nut with new ones after removal.

6. After aligning the hole(A) of the lower spring seat with projection part(B) of the rear insulator, assemble them.



KXDSE37A



NOTE

The spring identification color mark should face down.


7. Remove the Special tool (J38402, A-20 and A-50).
8. Tighten the self-locking nut to the specified torque.

Tightening torque

40~55 Nm (400~550 kgf.cm, 29.6~40.7 lbf.ft)

TRAILING ARM

COMPONENTS EB4920CB




- 1. Rear suspension arm
- 2. Rear wheel and tire
- 3. Rear axle carrier
- 4. Trailing arm bracket

- 5. Trailing arm bracket mounting bolts
- 6. Trailing arm
- 7. Trailing arm-to-carrier mounting bolt

REMOVAL EFE207BF

1. After removing the bolt (C), detach the parking brake cable(B) which is fixed on the rear trailing arm bracket(A).



KXDSE39A

2. Remove the trailing arm mounting bolts(A,B) and the trailing arm bracket mounting bolts(C,D,E).




EXDSE40A

3. Remove the trailing arm.

REPLACEMENT ECE9ECC0


TRAILING ARM BUSHING

1. Install the special tool (09551 - 25000) on the trailing arm.



EHKD003A


2. Remove the trailing arm bushing.
3. Using the special tool (09551 - 25000), press-fit the rear trailing arm bushing.



EHKD004A

NOTE

Press-fit the bushing in the same way as shown in the illustration.




EHKD105A

INSTALLATION E716F23C

1. Installation is the reverse of the removal procedures.
2. Fully tighten the trailing arm mounting bolts to the specified torque under the unloaded vehicle on the ground.

REAR STABILIZER BAR

COMPONENTS EEDAE75E



- 1. Rear stabilizer bar link
- 2. Rear stabilizer bar
- 3. Rear stabilizer bush
- 4. Rear stabilizer bracket

- 5. Rear stabilizer bracket mounting bolt
- 6. Rear stabilizer bar link
- 7. Rear stabilizer bar link nut


EXDSE50A

REMOVAL EBDECC57

1. Remove the stabilizer bar link(A) from the rear strut assembly(B).

NOTE

If the ball joint(C) and nuts(D) turn altogether, use the pentagonal wrench to hold the stud(E).




KXDSE48A

2. Remove the rear stabilizer bar mounting brackets.
3. Remove the stabilizer bar link on the opposite side in the same way.
4. Remove the mounting nuts(B,C) of the exhaust pipe assembly(A).
5. Remove the stabilizer bar assembly.

INSPECTION E4D5D9EB

Check the stabilizer link ball joint(A) for rotating torque.



EHKD107A

1. If there is a crack in the dust cover, replace it and add grease.
2. Shake the stabilizer link ball joint stud several times.
3. Mount the self-locking nut on the ball joint, and then measure the ball joint rotating torque.

Standard value

1.7~3.2 Nm (17~32 kgf-cm, 1.25~2.36 lbf-ft)


4. If the rotating torque is above the upper limit of the standard value, replace the stabilizer link.
5. If the rotating torque is below the lower limit of the standard value, the ball joint may be reused unless it has drag and excessive play.

INSTALLATION EAB1BBE3

1. Install the bushing on the stabilizer bar.

 **NOTE**


After matching the bushing(D) in the inside of the white painted part(A) on the stabilizer bar(C), install the assembly.



EHKD011A

2. Install the bracket(B) on the bushing(D).
3. Tighten the components below to the specified torque as follows.

Rear stabilizer bar mounting bracket bolts (A) :
17~26 Nm (170~260 kgf-cm, 13~19 lbf-ft)
Rear stabilizer bar link mounting nut (B) :
44~62 Nm (440~620 kgf-cm, 32~45 lbf-ft)




EXDSE48B

TIRES AND WHEELS

TIRE

TIRE ROTATION E7E4FB1C

Rotate the tires in the pattern illustrated.



EHDD854A

TIRE WEAR EC2EE401


1. Measure the tread depth of the tires.

Tread depth of tire [Limit] : 1.6 mm (0.06 in.)

2. If the remaining tread depth is less than the limit, replace the tire.

NOTE


When the tread depth of the tires is less than 1.6 mm (0.06 in.), the wear indicators will appear.



EXDSE59A

TIRE ROTATION

LEAD/PULL CORRECTION CHART



WHEEL


TIGHTENING WHEEL NUT EE1FEEB8

1. Tightening torque.
Steel and aluminum alloy wheel.

Specified torque
90~110 Nm (900~1,100 kgf-cm, 65~80 lbf-ft)


CAUTION

When using an impact gun, final tightening torque should be checked using a torque wrench.



KLCSD20A


2. Tightening order.
Check the torque again after tightening the wheel nuts diagonally.




KXDSS51A

WHEEL RUNOUT EAAEB01B

1. Jack up the vehicle and support it with jack stands.
2. Measure the wheel runout with a dial indicator as illustrated.



[Radial direction]



[Axial direction]

ELCSD97A

3. Replace the wheel if the wheel runout exceeds the limit.

Wheel runout [Limit]

Steel wheel

Radial : 1.0 mm (0.04 in.) (Average of LH & RH)

Axial : 1.0 mm (0.04 in.)

Aluminum wheel

Radial : 0.3 mm (0.012 in.)

Axial : 0.3 mm (0.012 in.)


WHEEL ALIGNMENT E2A5C4BF

FRONT WHEEL ALIGNMENT

When using a commercially-available computerized four wheel alignment equipment (caster, camber, toe) to inspect the front wheel alignment, always position the car on a level surface with the front wheels facing straight ahead. Prior to inspection, make sure that the front suspension and steering system are in normal operating condition and that the wheels and tires face straight ahead and the tires are inflated to the specified pressure.

TOE-IN

Toe is a measurement of how much the front of the wheels are turned in or out from the straight-ahead position.



KXDSE53A

ITEM	Description
A	Negative (-) toe (toe out)
B	Positive (+) toe (toe in)

When the wheels are turned in toward the front of the vehicle, toe is positive (+) (toe in). When the wheels are turned out toward the front of the vehicle, toe is negative (-) (toe out). Toe is measured in degrees, from side to side, and totaled.

Toe-in (B-A or angle a+b) is adjusted by turning the tie rod turnbuckles. Toe-in on the left front wheel can be reduced by turning the tie rod toward the rear of the car. Toe-in change is adjusted by turning the tie rods for the right and left wheels simultaneously at the same amount as follows.

Standard value

Toe-in (B-A) mm (in.) : 0±2 mm (0±0.08 in.)

NOTE

- Toe-in adjustment should be made by turning the right and left tie rods at the same amount.


- When adjusting toe-in, loosen the outer bellows clip to prevent twisting the bellows.
- After the adjustment, tighten the tie rod end lock nuts firmly and reinstall the bellows clip.
- Adjust each toe-in to be the range of ±1mm.

Tie rod end lock nuts tightening torque

50~60 Nm (500~600 kgf-cm, 37~43 lbf-ft)

CAMBER

Camber is the inward or outward tilting of the wheels at the top.



KXDSE51A

ITEM	Description
A	Positive camber angle
B	True vertical
C	Pivot centerline

When the wheel tilts out at the top, then the camber is positive (+).

When the wheel tilts in at the top, then the camber is negative (-).

The steering knuckle which is installed with the strut assembly is pre-set to the specified camber at the factory and doesn't need to be adjusted.

Camber : 0°±30

CASTER

Caster is the tilting of the strut axis either forward or backward from vertical. A backward tilt is positive (+) and a forward tilt is negative (-).

Caster is pre-set at the factory and doesn't need to be adjusted. If the caster is not within the standard value, replace the bent or damaged parts.

Caster : 2°36' ± 30'

NOTE

1. The worn loose or damaged parts of the front suspension assembly must be replaced prior to measuring front wheel alignment.
2. Measure the wheel alignment by using special tool (09529-21000).
3. Camber and caster are pre-set to the specified value at the factory and don't need to be adjusted.
4. If the camber and caster are not within specifications, replace bent or damaged parts.
5. The difference of left and right wheels about the camber and the caster must be within the range of $0^\circ \pm 30'$.

REAR WHEEL ALIGNMENT

TOE-IN

Standard value : 3~7 mm (0.12~0.28 in)

- Adjust the toe-in by turning the tie rod(C) end of the rear suspension arm(A).


Left tie rod : Clockwise direction → toe-in
 Right tie rod : Clockwise direction → toe-out
 The variation of toe by a rotation of the tie rod : About 6mm (0.6°)

CAUTION

1. Each toe should be within $2.5 \pm 1\text{mm}$ (0.098 ± 0.039 in.).
 If the difference between right and left is not within +2mm (0.079 in.), repeat adjustment.
2. After adjusting the tie rod(C), tighten both nuts(B) to the specified torque.

Specified torque


50~60 Nm (500~600 kgf-cm, 37~43 lbf-ft)



EHKD012A

CAMBER

Camber is the inward or outward tilting of the wheels at the top.



KXDSE52A

ITEM	Description
A	Positive camber angle
B	True vertical
C	Pivot centerline

When the wheel tilts out at the top, then the camber is positive (+).

Standard value : $-55' \pm 30'$

Difference between right and left angle is within $0^\circ 30'$

NOTE

Camber is pre-set at the factory and doesn't need to be adjusted. If the camber is not within the standard value, replace the bent or damaged parts.